0101.11;5-4320-245-25P

# TM 5-4320-248-25P

DEPARTMENT OF THE ARMY TECHNICAL MANUAL

ORGANIZATIONAL, DIRECT AND GENERAL SUPPORT, AND DEPOT MAINTENANCE REPAIR PARTS AND SPECIAL TOOLS LIST

FUEL SYSTEM, TRANSFER, PORTABLE,
PUMP, CENTRIFUGAL, 100 GPM; TWO
DISCHARGE HOSE ASSEMBLIES;
ONE SUCTION HOSE ASSEMBLY;
TWO NON-AUTOMATIC NOZZLE
ASSEMBLIES; ONE MONITOR GO-NO-GO
GAĢE, 100 GPM; 3 HP GASOLINE ENGINE;
ONE BASKET ASSEMBLY KENCO
MODEL 114MX1A FSN 4320-900-8544

TECHNICAL MANUAL
No. 5-4320-248-25P

HEADQUARTERS
DEPARTMENT OF THE ARMY
WASHINGTON, D. C., 12 February 1968

### Organizational, Direct And General Support, And Depot Maintenance

#### Repair Parts And Special Tools List

FUEL SYSTEM, TRANSFER, PORTABLE, PUMP, CENTRIFUGAL, 100 GPM; TWO DISCHARGE HOSE ASSEMBLIES; ONE SUCTION HOSE ASSEMBLY; TWO NON-AUTOMATIC NOZZLE ASSEMBLIES; ONE MONITOR GO-NO-GO GAGE, 100 GPM; 3 HP GASOLINE ENGINE; ONE BASKET ASSEMBLY KENCO MODEL

### 114MX1A

#### FSN 4320-900-8544

#### **CURRENT AS OF NOVEMBER 1967**

			Paragraph	Page
Section	I.	INTRODUCTION Scope General Explanation of columns	2	iii iii iii
		Special information  How to locate repair parts  Abbreviations  Federal supply codes for manufacturers  Recommendations for maintenance manual improvements	4 5 6 7	vi vi vi vi vi
	II.	PRESCRIBED LOAD ALLOWANCE		vii
	III.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT FOR ORGANIZATIONAL MAINTENANCE (NOT APPLICABLE)		
SECTION	IV.	REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE		
Group	01.	Engine 0100 Engine assembly 0106 Engine lubrication system 0107 Engine starting system		1
	03.	Fuel System 0301 Carburetor 0304 Air cleaner 0306 Tanks, lines, and fittings 0308 Engine speed governor		3 4
	04.	Exhaust System 0401 Muffler and pipes		5
	05.	Cooling System 0502 Shrouds		5
	06.	Electrical System 0605 Ignition components		6

#### TM 5-4320-248-25P

			Page
Group	15.	Frame 1501 Frame assembly	8
	99	Body Chassis or Hull and Accessory Items	
	24.	2202 Accessory items	9
		2210 Data plates and instruction holders	
	72.	Dispensing and Servicing Equipment Components	
		7202 Pumps and meters	
		7203 Valves, fittings, nozzles	
		7204 Miscellaneous parts and accessories	13
SECTION	V.	REPAIR PARTS FOR DS, GS, AND DEPOT MAINTENANCE	
Group	01.	Engine	
		0100 Engine assembly	
		0101 Crankcase, block, cylinder head0102 Crankshaft	
		0104 Pistons, connecting rods	
		0105 Valves, camshafts and timing system	
		0106 Engine lubrication system	19
		0107 Engine starting system	20
	03.	Fuel System	
		0301 Carburetor	
		0304 Air cleaner	
		0308 Engine speed governor	
	04.	Exhaust System	
	•	0401 Muffler and pipes	26
	05.	Cooling System	
		0502 Shrouds	26
	.06.	Electrical System	
		0605 Ignition components	27
	15.	Frame	
	00	1501 Frame assembly	28
	22.	Body Chassis or Hull, and Accessory Items 2202 Accessory items	20
		2210 Data plates and instruction holders	
	72.	Dispensing and Servicing Equipment Components	-
		7202 Pumps and meters	31
		7203 Valves, fittings, nozzles	33
		7204 Miscellaneous parts and accessories	35
SECTION	VI.	SPECIAL TOOLS, TEST AND SUPPORT EQUIPMENT FOR DS,	
		GS, AND DEPOT MAINTENANCE (NOT APPLICABLE)	
	VII.	INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER	
		CROSS_REFERENCE TO INDEX NUMBER	59

# SECTION I.

#### 1. Scope

This manual lists repair parts required for the performance of organizational, direct support, general support, and depot maintenance of the pump.

#### 2. General

- a. The repair parts list is arranged as follows:
  - Individual parts and major assemblies are listed alphabetically by item name within the numbered functional groups.
  - (2) Assembly components and subassemblies are intended and listed alphabetically by item name under major assemblies.
- b. This Repair Parts and Special Tools List is divided into the following sections.
  - (1) Prescribed Load Allowance (PLA)— Section II. A consolidated listing of repair parts quantitatively allocated for initial stockage at the organizational level. This is a mandatory minimum stockage allowance.
  - (2) Special Tools, Test and Support Equipment-Section III. A list of special tools, test and support equipment authorized for the performance of maintenance at the organizational level. (NOT APPLICABLE)
  - (3) Repair Parts—Section IV. A list of repair parts authorized for the performance of maintenance at the organizational level.
  - (4) Repair Parts—Section V. A list of repair parts authorized for the performance of maintenance at the direct

- support, general support, and depot level.
- (5) Special Tools, Test and Support Equipment—Section VI. A list of special tools, test and support equipment authorized for the performance of maintenance at the direct support, general support, and depot level. (NOT APPLICABLE)
- (6) Federal Stock Number and Reference Number Index—Section VII. A list of Federal stock numbers followed by reference numbers, appearing in all the listings, in ascending alphanumeric sequence cross-referenced to index number.

#### 3. Explanation of Columns

The following provides an explanation of columns in the tabular lists in Sections II through VI.

- a. Source, Maintenance, and Recoverability Codes (SMR).
  - (1) Source Code. Indicates the selection status and source for the listed item. Source codes used are:

#### Code Explanation

- P Applied to repair parts which are stocked in or supplied from DSA/GSA or Army supply system, and authorized for use at indicated maintenance categories.
- M Applied to repair parts which are not procured or stocked but are to be manufactured at indicated maintenance categories.
- A Applied to assemblies which are not procured or stocked as such but made up of two or more units, each of which carry individual stock numbers and descriptions and are procured and stocked and can be assemblied by units at indicated maintenance categories.

#### TM 5-4320-248-25P

Code	Explanation
X	Applied to parts and assemblies which are not procured or stocked, the mortality of which is normally below that of the applicable end item, and the failure of which should result in retirement of the end item from the supply system.
X1	Applied to repair parts which are not procured or stocked, the requirement for which will be supplied by use of the next higher assembly or components.
X2	Applied to repair parts which are not stocked. The indicated maintenance category requiring such repair parts will attempt to obtain them through cannibalization; if not obtainable through cannibalization, such repair parts will be requisitioned with supporting justification through normal supply channels.
C	Applied to repair parts authorized for local procurements. If not obtainable

- from local procurement, such repair parts will be requisitioned through normal supply channels with a supporting statement of nonavailability from local procurement.

  G Applied to major assemblies that are procured with PEMA (Procurement Equipment Missile Army) funds for initial
- cured with PEMA (Procurement Equipment Missile Army) funds for initial issue to be used as exchange assemblies at DSU and GSU maintenance level. These assemblies will not be stocked above DSU and GSU level or returned to depot supply level.

Note. Source code and level of maintenance are not shown on common hardware items known to be readily available in Army supply channels and through local procurement.

(2) Maintenance Code. Indicates the lowest category of maintenance authorized to install the listed item. The maintenance level codes are:

Code	Explanation
O	Organizational maintenance
F	Direct support maintenance
H	General support maintenance
D	Depot maintenance

(3) Recoverability Code. Indicates whether unserviceable items should be returned for recovery or salvage. Items not coded are expendable. Recoverability codes are:

Code	Explanation
R	Applied to repair parts and assemblies which are economically repairable at DSU and GSU activities and normally are furnished by supply on an exchange basis.
T	Applied to high dollar value recoverable repair parts which are subject to special handling and are issued on an exchange basis. Such repair parts normally are repaired or overhauled at depot maintenance activities.
U	Applied to repair parts specifically se- lected for salvage by reclamation units because of precious metal content, criti- cal materials, high dollar value re- usable casings or castings.

- (4) This column also lists, below the SMR code, an index number for each item in ascending numerical sequence, which is used to locate items in the publication when the Federal stock number and/or reference number is known.
- b. Federal Stock Number. Indicates the Federal stock number for the item.
- c. Description. Indicates the Federal item name and any additional description of the item required. A part number or other reference number is followed by the applicable five-digit Federal supply code for manufacturers in parentheses.
- d. Unit of Issue. Indicates the unit used as a basis for issue, e.g. ea, pr, ft, yd, etc.
- é. Quantity Incorporated in Unit Pack. Indicates the actual quantity contained in the unit pack.
- f. Quantity Incorporated in Unit. Indicates the quantity of the item used in the functional group.
- g. Fifteen-Day Organizational Maintenance Allowances.
  - (1) The allowance columns are divided into four subcolumns. Indicated in each subcolumn opposite the first appearance of each item is the total quantity of items authorized for the number of equipments supported. Subsequent appearances of the same item will have no entry in the allowance columns but will have in the description column a reference to the first appearance of the item. Items authorized

- for use as required but not for initial stockage are identified with an asterisk in the allowance column.
- (2) The quantitative allowances for organizational level of maintenance represents one initial prescribed load for a 15-day period for the number of equipments supported. Units and organizations authorized additional prescribed loads will multiply the number of prescribed loads authorized by the quantity of repair parts reflected in the appropriate density column to obtain the total quantity of repair parts authorized.
- (3) Organizational units providing maintenance for more than 100 of these equipments shall determine the total quantity of parts required by converting the equipment quantity to a decimal factor by placing a decimal point before the next to last digit of the number to indicate hundredths, and multiplying the decimal factor by the parts quantity authorized in the 51–100 allowance column. Example, authorized allowance for 51–100 equipments is 12; for 140 equipments multiply 12 by 1.40 or 16.80 rounded off to 17 parts required.
- (4) Subsequent changes to allowances will be limited as follows: No change in the range of items is authorized. If additional items are considered necessary, recommendation should be forwarded to U.S. Army Mobility Equipment Command for exception or revision to the allowance list. Revisions to the range of items authorized will be made by this Command based upon engineering experience, demand data, or TAERS information.

#### h. Thirty-Day DS/GS Allowances.

(1) The allowance colums are divided into three subcolumns. Indicated in each subcolumn, opposite the first appearance of each item, is the total quantity of items authorized for the number of equipments supported. Subsequent appearances of the same item will have no entry in the allow-

- ance column, but will have in the description column a reference to the first appearance of the item. Items authorized for use as required but not for initial stockage are identified with an asterisk in the allowance column.
- (2) The quantitative allowances for DS/GS levels of maintenance will represent intial stockage for a 30-day period for the number of equipments supported.
- (3) Determination of the total quantity of parts required for maintenance of more than 100 of these equipments can be accomplished by converting the equipment quantity to a decimal factor by placing a decimal point before the next to last digit of the number to indicate hundredths, and multiplying the decimal factor by the parts quantity authorized in the 51–100 allowance column. Example, authorized allowance for 51–100 equipments is 40; for 150 equipments multiply 40 by 1.50 or 60 parts required.
- i. One-Year Allowances Per 100 Equipments/Contingency Planning Purposes. Indicates opposite the first appearance of each item the total quantity required for distribution and contingency planning purposes. The range of items indicates total quantities of all authorized items required to provide for adequate support of 100 equipments for one year.
- j. Depot Maintenance Allowance Per 100 Equipments. Indicates opposite the first appearance of each item the total quantity authorized for depot maintenance of 100 equipments. Subsequent appearances of the same item will have no entry in this column, but will have in the description column a reference to the first appearance of the item. Items authorized for use but not for initial stockage are identified with an asterisk in the allowance column.

#### k. Illustration.

- (1) Figure Number. Indicates the figure number of the illustration in which the item is shown.
- (2) Item Number. Indicates the callout number to reference the item in the illustration.

#### TM 5-4320-248-25P

#### 4. Special Information

- a. Repair parts mortality has been based on 1000 hours of operation per year.
- b. Parts which require manufacture or assembly at a category higher than that authorized for installation will indicate in the source column the higher category.
- c. The following publication pertains to the pump and its components:

TM 5-4320-248-Operator, organizational, 15 direct support, general support, and depot maintenance manual.

#### 5. How to Locate Repair Parts

- a. When Federal stock number or reference number is unknown:
  - (1) First. Using the table of contents, determine the functional group within which the repair part belongs.
  - (2) Second. Find the illustration covering the functional group to which the repair part belongs.
  - (3) Third. Identify the repair part on the illustration, and note the illustration figure and item number of the repair part.
  - (4) Fourth. Using the Repair Parts Listing, find the functional group to which the repair part belongs and locate the illustration figure and item number noted on the illustration.
- b. When Federal stock number or reference number is known:
  - (1) First. Using the index of Federal stock numbers and reference numbers, find the pertinent Federal Stock number or reference number. This in-

- dex is in ascending alphanumeric sequence cross-referenced to an index number.
- (2) Second. Using the repair part listing, find the index number referenced in the index of Federal stock numbers and reference numbers.

#### 6. Abbreviations

GPM	Gallons Per Minute
hp	horse power
in	inch, inches
lg	long, length
mtg	mounting
std	standard
thd	thread
w/	with

#### 7. Federal Supply Codes for Manufacturers

Code	Manufacturers
08484	 Breeze Corporation Inc.
08645	 Briggs and Stratton Corp.
25500	 Goodyear Aircraft Corp.
38508	 Marsh Instrument Co., Division of
	Colorado Oil and Gas Corp.
	OPW Division of Dover Corp.
88795	 Kenco Pump Division of American
	Crucible Products Co.
9/00/05	 Bendix Corp., The Filter Division
96906	 Military Standards

### 8. Recommendations for Maintenance Manual Improvements

Report of errors, omissions, and recommendations for improving this publication by the individual user is encouraged. Reports should be submitted on DA Form 2028 (Recommended Changes to DA Publicaions) and forwarded direct to the Commanding General, U. S. Army Mobility Equipment Command, ATTN: AMSME-MPP, 4300 Goodfellow Blvd., St. Louis. Mo. 63120.

## SECTION II PRESCRIBED LOAD ALLOWANCE

(1)	(2)	(8) Qty	1	(4) 5-day org m	aint. alw	
Federal stock number	Description	inc in unit	(a) 1-5	(b) 6-20	(c) 21–50	(d) 51-100
number	useable on code	pack	1-6	6-20	21-50	51-100
	Group 01—ENGINE 01.00—ENGINE ASSEMBLY					
805-828-0783	GASKET SET: engine	1	*	*	2	2
000-020-0100	(08645) 297275				2	
	Group 0106—ENGINE LUBRICATION					
	SYSTEM					
805-776-2282	GROMMET: breather cover		*	*	2	2
	(08645) 66578 Group 0107—ENGINE STARTING					
	SYSTEM					
2990-174-5255	ROPE, ENGINE STARTER: 47 1/8 in. lg.		2	2	4	8
	(08645) 294584					
	Group 03—FUEL SYSTEM					
2010 000 50'61	0301—CARBURETOR		*	*	2	2
2910-920-5361	CARBURETOR ASSEMBLY (08645) 296784		·			2
	0304—AIR CLEANER					
2940-688-7912	FILTER ELEMENT, AIR INTAKE		*	*	*	2
23-40000 ( 3-1-2	(08645) 27987					-
	0308—ENGINE SPEED GOVERNOR					
2990-624-0260	SPRING, CONTROL ROD		*	*	*	2
	(08645) 26855	İ	*			2
29910-8198-2097	SPRING, GOVERNOR LINK   (08645) 260585		T		T	2
5340-945-0493	SPRING, GOVERNOR LEVER		*	*	*	2
210 010 0100	(08645) 260545			]		l
	Group 06-ELECTRICAL SYSTEM					
	0605—IGNITION COMPONENTS					Į.
2805-624-0284	PARTS KIT, IGNITION: breaker points		*	2	2	4
	and condenser (08645) 294628					
2920-294-3747	PLUG, SPARK W/GASKET (08645) CJ8		2	2	4	8
5970-789-1925	INSULATOR, PLATE: terminal;		*	*	2	2
7010 100 1000	condenser lead (08645) 66935					_
	Group 22—CHASSIS OR HULL,					
	AND ACCESSORY ITEMS					
	2202—ACCESSORY ITEMS					
4720-916-1883	HOSE ASSEMBLY, DISCHARGE:		*	*	*	2
4500 000 0505	rubber w/coupling (88795) SX937		*	2	2	2
4730-360-0595	GASKET (81718) H6430M			"	-	
	Group 72—DISPENSING AND					1
	SERVICING EQUIPMENT					1
	COMPONENTS					
	7204-MISCELLANEOUS		l		l	
	PARTS AND ACCESSORIES					
4320-920-5342	CLAMP, HOSE		*	*	*	2
4000 070 4770	(88795) QS200M28A		0			
4930-872-1779	ELEMENT, FILTER (90005) 041420S		2	2	4	8
5330-526-7517	O-RING, 100 GPM GAGE		*	2	2	4
COM SWOTHER	(96906) MS29513-249					

		- I														
(8) LUS-	TRATION (a) (b)	ITEM NO.										*	=	m	2	_
12	(a)	FIG NO.									2	77	~	r.	2	2
	ONAL ALW	(4) 51-100				~						*	*		~	
6	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(c) 21-50				2	き	0.00	90 .			*	*		~	
	ORG/ NTEN/	(b) 6-20.				*	SEE GRP 0304		GRP 0.			*	*		*	
	15-DA) MAI	(a) 1.5				*	SEE	SEE GRP	SEE			*	*		*	
(9)	ÇΩ.≅						~		-		0	_	_	-	_	_
<u>(S</u>	ŽŠ≅ ŽÕŠ≅	PACK			.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,											
€ €	ISSU 3					E	Ε¥	E.A.	<b>₹</b>		EA	EA	ΕA	EA	E A	EA
(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE	SECTION IV - REPAIR PARTS FOR ORGANIZATIONAL MAINTENANCE	GROUP O1 - ENGINE	0100 - ENGINE ASSEMBLY	GASKET SET: ENGINE 297275 (08645)	GASKET: AIR CLEANER 27660 (08645)	GASKET: CARBURETOR HIG 27402 (08645)	GASKET: FUEL TANK MTG 27911 (09645)	0106 - ENGINE LUBRICATION SYSTEM	BOLT, ASSEMBLED WASHER: BREATHER MTG 93394 (08645)	BREATHER, VALVE CHAMBER 294178 (08645)	CAP, OIL FILLER: CRANKCASE COVER 69345 (08645)	GASKET: VALVE CHAMBER COVER MTG 27549 (OBG45) (COMPONENT OF GASKET SET, STOCK NO. 2805-828-0783, GROUP 0100)	GROMMET: BREATHER COVER 66578 (08645)	GROMMET, BREATHER TUBE 67608 (08645)
(2)	FEDERAL STOCK					2805-828-0783	2940-608-8514	2940-171-7935	2910-898-2094		5306-073-8255	2805-624-0282	2805-422-5804	2805-678-4431	2805-776-2282	
ε	SMR CODE	INDEX NO.	10000	00001A	00001B	P 0 00000	х1 00005	x1 00006	x1 00000	61,000	000050	P 0 00051	P 0 00052	x1 00053	P 0 00054	X20 00055

ε	(2)	. (c)	<u>4</u>	(2)	(9)		(7)	(,		(8)
SMR CODE	FEDERAL STOCK	DESCRIPTION	123UE	Çŏ.≅	ŽNZ Z		15-DAY ORGANIZATIONAL MAINTENANCE ALW	NIZATIO NCE /	NAL W	TRATIC
INDEX NO.		REFERENCE NO. & MFR. CODE		UNIT PACK	i n	(a) 1-5	(b) 6-20	(c) 21-50	rd) 51-100	FIG NO.
00056	4730-192-9481	NIPPLE, PIPE; ail FILLER, 3/4 IN, 2 IN LG 91258 (08645)	EA							2
P 0	2805-849-3141	TUBE, BREATHER 230634 (08645)	EA			*	*	*	*	2
00058		0107 - ENGINE STARTING SYSTEM								
P 0 00059	2990-907-064 <sub>th</sub>	CLUTCH ASSEMBLY STARTER 298310 (08645)	ΕA		-	*	*	*	*	
x 00060	3110-100-6180	BEARING, BALL: CLUTCH HOUSING 63770 (08645)	EA		9					<i>≠</i>
x1 00061	5840-787-6662	BUMPER, STARTER PULLEY 66528 (08645)	EA							#
x1 00062	2990-768-0723	GRIP, ENGINE STARTER 66728 (08645)	Ε¥							#
x20 00063		HOUSING, STARTER CLUTCH 211383 (08645)	EA							<i>*</i>
x1 0006₽	5315-855-4336	PIN, STARTER GRIP 230228 (08645)	Ε¥							<i></i>
x1 00065	2990-786-2030	PULLEY, ENGINE STARTER 294088 (08645)	ΕA							<i>#</i>
P 0 00066	2990-930-1737	RATCHET, REWIND 298436 (08645)	ΕA			*	*	*	*	<i>*</i>
P 0 0000	2990-174-5255	ROPE, ENGINE STARTER: 47 1/8 IN LG 294584 (08645)	EA			α	7	<b>4</b>	∞	<i></i>
X20 00068	2990-930-1738	SCREEN, REWIND STARTER PULL 221661 (08645)	EA							<i>*</i>
69000	5305-719-4603	SCREW, ASSEMBLED WASHER: SCREEN HTG 93042 (08645)	EA		#					<i>*</i>
										_

		•														
(8) ILLUS-	NO (9)	ITEM NO.	3	1,4	13			7	9	12	2		2	κ	<b>4</b>	,-
	(A)	FIG NO.	ŧ	#	#			9	9	9	9		9	9	9	9
	ONAL ALW	(d) 51-100	*					N					*	N		
_	ZZATE ZCE	(c) 21-50	*					2					*	*		
S	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(b) 6-20	*					*					*	*		
	IS-DAY MAII	(o) 1-5	•					*					*	*	<del>~~~</del>	
	_ Ç∑≧									<del>(1)</del>	~		-			_
_	Ç≅Z															
		O TINU	ΕA	EA	EA			EA	EA	EA	EA		EA	EA	E A	EA
											ш		ш	<u> </u>	ш	لبا
		N COD														
		USABLE ON CODE														
		us,														
											<b></b>					
	NO										Æ MTG				3-0783	
2	DESCRIPTION									FUEL	SCREW, CAP, HEXAGON HEAD: CARBURETOR TO ENGINE 1/4-20 THO SIZE, 3/4 IN LG 93357 (08645)				GASKET: AIR CLEANER (COMPONENT OF GASKET SET STOCK NO. 2805-828-0783, SEE GROUP 0100) 27660 (08645)	
	DESC								° ×	SCREW, ASSEMBLED WASHER; CARBURETOR TO FUEL TANK MTG, 10-32 THD SIZE, 5/8 IN LG 93341 (08645)	OR TO				% 28	
					AL ING				Stock No. 0100)	BURET 5/8 11	BURET				Ž V OC	
		ODE	œ	<b>E</b>	WASHER, RUBBER, RATCHET SEALING 68238 (08645)					ig CAR	): CAR			ITAKE	ET ST	
		REFERENCE NO. & MFR. CODE	SPRING, REWIND STARTER 294303 (08645)	WASHER, CLUTCH RETAINER 221653 (08645)	RATCH	STEM	TOR	<b>&gt;</b> -	SKET; CARBURETOR HTG 27402 (08645) (COMPONENT OF GASKET SET, 2805-828-0783, SEE GROUP	REW, ASSEMBLED WASHER: CAI TANK MTG, 10-32 THD SIZE, 93341 (08645)	3/4 r			FILTER ELEMENT, AIR INTAKE 27987 (08645)	KER SKET S	ρĸ
		8 .×	NND 8	тсн R 8645)	BER, .	EL SY	0301 - CARBURETOR	SEMBL 8645)	RETOR 645) or GA 783, 3	20-32 84-32 84-35	XAGON	ANER	NTAKE 3645)	NT, 4	cleAb or GAS 00) 045)	SCREW, AIR CLEANER
		NCEN	, REV 103 (0	) 53 (0	8 (08	5	- CA	OR AS	CARBUI 2 (08) NENT 828-0	SSEMB 116, 1	ль, не тно з 7 (986	IR CLE	ξΕR, Ι	ELEME 7 (086	A1R of 01 (086)	AIR C
		EFERE	29 <sup>43</sup>	ASHER 2216	ASHER 6823	GROUP 03 - FUEL SYSTEM	0301	CARBURETOR ASSEMBLY 296784 (08645)	GASKET: CARBURETOR MTG 27402 (08645) (COMPONENT OF GASKET 2805-828-0783, SEE C	EW, A	74-20 93351	0304 - AIR CLEANER	AIR CLEANER, INTAKE 294870 (08645)	1.TER 27987	GASKET; AIR CLE (COMPONENT OF G SEE GROUP 0100) 27660 (08645)	REW,
		æ	8	3	3	GRO		CAR	GAS	SCF	SCRE 1,	0307	AIR	Ē.	8 ° 8	SC
	₩~:	×	4104					-5361	-7935				1599	2167.	8514	
2	FEDERAL	NOMBE	2990-769-4104					2910-920-5361	2940-171-7935				2940-294-1599	2940-688-7912	2940-608-8514	
			1		~	<u></u>	ě			- 2						
ε	SWR	INDEX NO.	P 0 00070	x20 00071	x20 00072	00073	00073	P 0 0007 <sup>4</sup>	x1 ∞009≱	X20 00095	x20 00097	00100	P 0 00101	P 0 00102	X1 00103	X20 0010≱

11   12   13   14   15   15   15   15   15   15   15	Т		5 .														
EA 1 1	(8) US- AT10N	(q)	IT EM NO.	·	6	=		2			- 2	12	91	_	<u> </u>	ε	9
(4) (5) (6) (7) (1) (7) (1) (7) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	ILL TR,	, o			9	9	9	9		<u>~</u>	∞	∞		∞	∞.	∞	
(6) (6) (7) (7) (7) (7) (8) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	ONAL AI W	ור אר ביו				*											<u> </u>
USABLE ON CODE  EA  EA  CABLE ON CODE  CABLE ON COD	(7)	וארם	(c) 21-50			*							<del></del>		<del></del>		
USABLE ON CODE  EA  EA  CABLE ON CODE  CABLE ON COD	Y ORG		(b) 6-20														
CABLE ON CODE  USABLE ON CODE  EA E E E E E E E E E E E E E E E E E	15-DA	W	(a) 1-5			*											
LA LE ON CODE LA LE LA LOE ISSUE 🕏	(6) OTY	Z Z Z	5		-	1		-			-		_		_		<b>f</b>
LA LE ON CODE LESSUE ®	(5) QTY	ا 2 <u>ح</u>	PACK														
					EA	EA	EA	EA		EA	EA	EA	EA	EA	EA ,	EA	EA
CREC CAS 3306 3306 CREC CAS CAS CAS CAS CAS CAS CAS CAS CAS CA	(3)	DESCRIPTION		- TANKS, LINES, AND FITTINGS	, FUEL 296591 (оВС <del>И</del> 5)	P, FUEL TANK 293270 (08645)	SKET: FUEL TANK MTG 27911 (OBGH5) (COMPONENT OF GASKET SET STOCK NO. 2805-828-0783, SEE GROUP 0100)		- ENGINE SPEED GOVERNOR	IING: aovernor Lever 23688 (08645)	KET; CONTROL ROD MTG 221384 (08645)	KET, MECHANICAL GOVERNOR: THROTTLE CONTROL 220691 (08645)	r, governor 294077 (овс45)	R, MECHANICAL GOVERNOR 220690 (08645)	, governor 260544 (08645)	CONTROL ROD 230149 (08645)	сонтвоц; соусвнов 230680 (08645)
(2) FEDERAL STOCK NUMBER 2910-707-7503 2910-898-2094 2990-787-6665	_	CODE	NDE X NO.	c0105	x20 00106	P 0 00107	x1 00108	"20 00109	00110	X20 00117	x20 00115	x20 00116	x20 00119	x20 00120	X20 00121	X20 .	x20 00125



Color   Colo	Г	z	2				6												
Code	(8)	LLUS- RATIOI	(a) (c	G ITEM				8 17	.₹ ———	3 15	13	 				~~~~			
CODE	-		┸┪		_		~	~ 				<del></del>			ω	~			<i>*</i>
CODE		TIONAL	AL.		_											*			
CODE	6	ANIZA	ANCE	(c)					*	*	*					*			
CODE		Y ORG	IN TEN	(b) 6-20					*	*	*					*			
#ER: BRACKET WTG, 10-24 THO SIZE, USABLE ON CODE   15   16   17   17   17   17   17   17   17		15-DA	¥	(o) 1-5					*	*	*					*			
(4)   (3)   (1)	(9)	QTY	y z	Z Z		-	-	_	-	-	_	2				_			_
R. CODE  R. CODE  R. CODE  R. CODE  R. CODE  R. CODE  RET BRACKET MTG, 10-24 THO SIZE,  B. IN LG  KKIT AND LEVER MTG  CAN THE STAND LEVER MTG  KTEM  W. D. PIPES  FLER  FLER  FLER  FACTOR OF SIZE,  FACTOR OF SIZ	(5)																		
R. CODE  R. CODE  HER: BRACKET WIG, 10-24 THO SIZE,  HER: THROTTLE LEVER WIG,  SIN LG  KRET AND LEVER WIG  STEM  40 PIPES  FTLER	(4)					E A	EA	E A		E.A	E A	E A			<b>4</b>	E A			¥.
R. CODE  R. CODE  HER: BRACKET MTG, 10-24 THD SIZE, HER: THROTTLE LEVER MTG, S IN LG  KKET AND LEVER MTG  YSTEM  YD PIPES FFLER				ñ								_							
	(3)		DESCRIPTION			SCREW, ASSEMBLED WASHER: BRACKET MTG, 10-24 THD SIZE, 9/16 IN LG 93062 (08645)	SCREW, ASSEMBLED WASHER: THROTTLE LEVER MTG, 10-24 THD SIZE, 3/8 IN LG 93067 (08645)	SCREW, MACHINE: LEVER MTG 93100 (08645)	SPRING, CONTROL ROD 26855 (08645)	SPRING, GOVERNOR LEVER 260545 (08645)	SPRING, GOVERNOR LINK 260585 (08645)		GROUP ОЙ – EXHAUST SYSTEM	0401 - MUFFLER AND PIPES	LOCKNUT, EXHAUST, MUFFLER 91811 (08645)	MUFFLER, EXHAUST 89966 (08645)	GROUP 05 - COOLING SYSTEM	0502 - SHROUDS	COVER, CYLINDER HEAD 220581 (08645)
			CODE	INDEX NO.		x20 00126	00128	00129	P 0 00131	P 0 00132	P 0 00133	x20 0013⁴	00137	00137A	x20 00138	P 0 00139	04100	001 10A	X20 00141

	NO (9)	ITEM NO.		6	=	ω	01		0	72	12	16		<b>7</b> .	m	9
(8)	TRATION (b)	FIG NO		9	9	9	9		∞	8	ω	ω	ω	∞.	ω	80
	ONAL ALW	(d) 51-100			*											_
(7)	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(c) 21-50			*											
	Y ORGA	(b) 6.20			*					- <del></del>						
	15-DA MA	(a) 1-5			*											
(9)	≻UZ ZUZ	- CN		-	-	-	<b>,</b>	·				-	_		-	
(2)	, ΣΩΣ ΣΩΣ	UNIT PACK														
(4)	∃USSI ∃	O TINU		ΕA	ΕA	EΑ	EA		EA	EA	ΕA	EA	EA	ΕΛ	EA	ΕA
(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE	0306 - TANKS, LINES, AND FITTINGS	TANK, FUEL 296591 (08645)	CAP, FUEL TANK 293270 (08645)	GASKET; ruel tank mtg 27911 (08645) (Component of GASKET SET Stock No. 2805-828-0783, See Group 0100)	SCREW, CAP, HEXAGON HEAD: TANK MTG, 1/4-20 THD SIZE 93343 (08645)	0308 - ENGINE SPEED GOVERNOR	BUSHING; GOVERNOR LEVER 23688 (OBG45)	BRACKET: CONTROL ROD MTG 221384 (08645)	BRACKET, MECHANICAL GOVERNOR: THROTTLE CONTROL 220691 (08645)	LEVER, GOVERNOR 294077 (08645)	LEVER, MECHANICAL GOVERNOR 220690 (08645)	LINK, GOVERNOR 260544 (08645)	NUT, CONTROL ROD 230149 (08645)	ROD, CONTROL: covernor 230680 (08645)
(2)	FEDERAL STOCK NIMRER				2910-707-7503	2910-898-2094					2990-787-6665			2990-920-5347		·
Ξ	SMR CODE	INDEX NO.	00105	x20 00106	P 0 00107	x1 00108	"20 00109	00110	X20 00117	X20 00115	x20 00116	x20 00119	x20 00120	X20 00121	x20 .	X20 00125



											[
ε	(2)	(6)	( <del>4</del> )	(2)	(9)		(7)			(8) LLUS-	
SMR CODE	FEDERAL STOCK	DESCRIPTION	F ISSUI	Çĕ.Z	ÇNZ Z	15-DAY MAII	ORGANI	15-DAY ORGANIZATIONAL MAINTENANCE ALW		TRATION (a) (b)	
INDEX NO.	NOMBER			PACK	is S	(e) :				FIG ITEM	Σ.
		REFERENCE NO. & MFR. CODE	<del> </del>			2	0-50	21-50	21-100	+	<del>-</del>
x20 00126		SCREW, ASSEMBLED WASHER: BRACKET MTG, 10-24 THD SIZE, 9/16 ім LG 93062 (08645)	ΕA		_					8 =	
0 00128	5306-543-5219	SCREW, ASSEMBLED WASHER: THROTTLE LEVER MTG, 10-24 THD SIZE, 3/8 IN LG 93067 (08645)	EA		-					8	
0 00129	5305-719-4783	SCREW, MACHINE: LEVER MTG 93100 (08645)	EA		-					8 17	
P 0 00131	2990-624-0260	SPR1NG, CONTROL ROD 26855 (08645)	EA		-	*	*	*	2	<i>≉</i> 	
P 0 00132	5340-945-0493	SPRING, GOVERNOR LEVER 260545 (08645)	EA		-	*	*	*	2	8 15	
P 0 00133	2990-898-2097	SPRING, GOVERNOR LINK 260585 (08645)	EA		-	*	*	*	2	8 13	
x20 ∞13 <sup>4</sup>		WASHER: GOVERNOR BRACKET AND LEVER MTG 66432 (08645)	EA		2					8	
00137		GROUP OH - EXHAUST SYSTEM	<del></del> -								
00137A		O401 - MUFFLER AND PIPES	<del></del>								
x20 00138	5975-152-1075	LOCKNUT, EXHAUST, MUFFLER 91811 (08645)	EA		-					<u>~</u>	
P 0 00139	2990-269-7145	MUFFLER, EXHAUST 89966 (08645)	ΕA		-	*	*	*	*	8	
00140		GROUP 05 - COOLING SYSTEM									
00140A		o5o2 - SHROUDS							-		
X20 00141	293c-537-1363	COVER, CYLINDER HEAD 220581 (08645)	EA					<u></u>		- #	
5						1	1	1	1	-	7

(8) LUS-	TRATION	ITEM NO.		7	≉	-	7	7	∞			9	17	15	٠.	8	19	
	(o)	F1G NO.		σ	#	5	<b>4</b>	2	#			6	0/	6	6	<i>_</i>	6	
	ONAL ALW	(4)										*				*	α .	
(1)	NIZATI	(c)										*				*	N	
5	15-DAY ORGANIZATIONAI MAINTENANCE ALW	(b)										*				*	*	
	15-DA MAI	(0)										*				*	*	
(9)	ÇN Z	LIN .			<del>-</del>	-	m	-	က			-	_		-	_	-,	
(3)	ÇΩ.Z	UNIT																
€ 3	IUSSI 3	IO TIMU		E.A	EA	ΕA	EA	EA	EA			EA:	ΕA	EA	EΑ	ξ¥	EA	
(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE		DEFLECTOR, AIR 220692 (08645)	HOUSING, BLOWER 294260 (08645)	SCREW, ASSEMBLED WASHER: CYLINDER SHIELD MTG 93042 (08645)	SCREW, CAP, HEXAGON: SHROUD MTG, 1/4-20 THD \$12E, 9/16 IN LG 92666 (08645)	SHIELD, CYLINDER 220478 (08645)	WASHER, LOCK: INTERNAL AND EXTERNAL TEETH, SHROUD MTG. 1/4 IN SCREW SIZE 92778 (08645)	GROUP O6 - ELECTRICAL SYSTEM	0605 - IGNITION COMPONENTS	ARMATURE, MAGNETO 298502 (08645)	BOLT: CONDENSER LEAD MTG 92786 (08645)	CLAMP: condenser mtg 260455 (08645)	cover, contact set 220366 (08645)	FLYMHEEL ASSEMBLY, MAGNETO 296884 (08645)	INSULATOR, PLATE: TERMINAL, CONDENSER LEAD 66935 (08645)	
(2)	FEDERAL STOCK	NUMBER	,	2930-537-1360		5305-719-4603						2920-920-5373	5305-010-0752		2920-537-1365	2805-920-5385	5970-789-1925	,
ε	SMR CODE	NDE X		X20 00142	x20 00143	0 00144	x20 00145	x20 00146	x20 00147	84100	00148A	P-0 00149	00150	x20 00151	x20 00152	P 0 00153	P 0.	

Z	<u>(a)</u>	ITEM NO.	Τ	 <u> </u>	ر م	 გ	21	=	ლ	£ ,	 ∞ .		0 ,	<u>∞</u> ,	<u>~</u>	91	<b>A</b>
ILLUS- TRATION	(o)	FIG.	-		6	6	6	9	6	6	6	<u>-</u>			<del>-</del>	6	
	╌		51-100	 *	*		<del></del>		∞	*							
(/) 15DAY ORGANIZATIONAL	E AL		21-50 51-	 *	*		8		<del>*</del>	*							
(/) RGANIZ	ENANC		6-20	*	*		~		۲۵	*							•
-DAY 0	MAIN		1-5 6-	 *	*		*		۰.	*		<del>- ;</del>					<del></del>
	<u>∑</u> ≥		7	 	_			_	_	_	m	_	7	_	7	_	
			+	 					,								
SUE &		PACK	10	 E A	EA	EA	EA	⋖	⋖	⋖		«	∢	⋖	⋖	⋖	
A 3112	31 36		$\dashv$	ш	ш	шĬ	ш	EA	EA	EA	EA	EA	EA	EA	EA	EA	-
			USABLE ON CODE														
(3)	DESCRIPTION		REFERENCE NO. & MFR. CODE	KEY, MACHINE: FLY WHEEL MTG 61760 (08645)	LEAD, ELECTRICAL, SPARK PLUG: ARMATURE 293141 (08645)	NUT, HEXAGON: CONDENSER LEAD MTG 90576 (08645)	PARTS KIT, IGNITION: BREAKER POINTS AND CONDENSER 294628 (08645)	SPRING, HELICAL, EXTENDED: BREAKER ARM 26018 (08645)	PLUG, SPARK, WITH GASKET CJ8 (08645)	PLUNSER, BREAKER POINT 65704 (08645)	SCREW, ASSEMBLED WASHER 93381 (08645)	SCREW, ASSEMBLED WASHER: CONDENSER CLAMP MTG 93042 (08645)	SCREW, ASSEMBLED WASHER: DUST COVER MTG 93014 (O8645)	WASHER, FLYWHEEL MTG 220865 (08645)	WASHER, LOCK: CONDENSER LEAD MTG	WIRE, ELECTRICAL: LEAD, CONDENSER TO INSULATOR 293999 (08645)	
(2)	FEDERAL STOCK	UMBER		5315-598-5970	2920-213-1147	5310-596-5224	2805-624-0284	5340-286-4566	2920-294-3747	2920-356-1333	5305-992-0440	5305-719-4603	5305-543-5220	5310-721-4667	5310-011-55 <sup>44</sup>	6150-624-0279	
	世"言	<b>~</b>		53	ζ,	Š	Ñ	5	Ø.	Č.	ŗ.	ĬC.	2	2	2	9	

Γ	z c	O.					<u>س</u>	<u></u>	6	5	9		~	<b>#</b>	7	*******	
(8)	TRATION (a)	ITEM NO.				<u>~</u>					<del></del>						-
-		5 N				٥	5	2	<u> </u>	<u> </u>	2	2	2	2	2	 	$\dashv$
	IONAL AL#	(4)													70.0		_
(2)	ANIZAT ANCE	(c) 21-50														····	
	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(b) 6-20													,		
	15-DA MA	(0)															
(9)	ÇN Z ∑N Z	E N				-	_		#	0	#	N	2	2	4		
(5)	ŽNZ ZOZ	PACK															
<u>(5</u> 3	JUSSI 30				EA	ΕA	E.A	EA	EA	EA	EA	ΕA	EA	EA	ΕA		
(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE	GROUP 15 - FRÀME	1501 - FRAME ASSEMBLY	BASE ASSEMBLY SX1610 (88795)	BASE, LEFT SX1644A (88795)	ВАSE, RIGHT SX1644B (88795)	BASKET, CARRYING SX700 (88795)	BOLT: BASE MTG, 5/16-18 THD SIZE, 1 1/2 IN LG BEOO2A7 (88795)	BOLT: SUPPORT AND SPACER MTG, 3/8-16 THD SIZE, 9 IN LG SX1094 (88795)	NUT, HEXAGON: BASE MTG, 5/16-18 THD SIZE BGOOZB2 (88795)	NUT, STOP: SUPPORT AND SPACER MTG, 3/8-16 THD SIZE SX989 (88795)	SPACER, BASE: 4-5/8 IN LG SX988 (88795)	SUPPORT, FILTER ASSEMBLY SX1091 (88795)	WASHER, LOCK: BASE MTG, 5/16 IN SCREW SIZE AHOO2B1 (88795)		
(2)	FEDERAL STOCK	NOMO															
ε	SMR CODE	INDEX NO.	00168	00168A	X20 00169	X20 00170	x20 00170A	x20 00171	x20 00172	x20 00173	x20 00174	x20 00175	x20 00176	x20 00177	x20 00178		

18, LUS-	TRATION	ITEM NO.						<b>*</b>	N	ω	10				
֡֝֝֝֝֟֝֝֟֝֝֟֝֟֝ <u>֚֚</u>	(a)	PFG NO.					=	=	=	=	=				
	ONAL ALW	(d) 51-100				*	8							0	
ŝ	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(c) 21-50				*	*							N	
٥	/ ORGA NTENA	(b) 6-20				*	*							2	
	15-DA) MAI	(a) 1.5				*	*							*	
9	ŽΩZ ZΩZ Z			····	-	-	8	2	-	12	8	3	9	m	
ĵ.	ĻΩ≅ Z							,							
€ E	IUSSI 30				EA	EA	EA	ξA	EA	EA	EA	E A	EA	EA	
. (E)	DESCRIPTION	REFERENCE NO. & MFR. CODE	GROUP 22 - BODY CHASSIS OR HULL, AND ACCESSORY ITEMS	2202 - ACCESSORY ITEMS	ACCESSORY HOSE AND NOZZLE PACKAGE SX1077 (88795)	HOSE ASSEMBLY, SUCTION, RUBBER: WITH COUPLING SX848 (88795) (COMPONENTS SAME AS HOSE ASSEMBLY, STOCK NO. 4720-916-1883, EXCEPT WHERE INDIVIDUAL COMPONENTS ARE ANNOTATED)	HOSE ASSEMBLY, DISCHARGE: RUBBER W/COUPLING SX937 (88795)	HOSE, DISCHARGE: 50 FT 546-622-048 (25500) (USED WITH HOSE ASSEMBLY, STOCK NO. 4720-916-1883, ONLY)	HOSE, SUCTION, FUEL: 10 FT 541-621-048 (25500) (USED WITH HOSE ASSEMBLY, STOCK NO. 4720-946-9960 ONLY)	CLAMP, HOSE AROO5A1 (08484)	COUPLING, HALF QUICK 633C (81718)	COUPLER, HOSE, SHANK SX1616 (81718)	FINGER RING SX1605 (88795)	GASKET H6430M (81718)	
(Z)	FEDERAL STOCK	NOMBER				4720-946-9960	4720-916-1883				4730-542-4031			4730-360-0595	

	NO (9)	NO.	·	m	6			5		9	<b>→</b>					
(8)	(a) (b)	NO N		=	=	=		=		=	=					
-		8						•				.,				
	AT IONA AL I												<del>, , , , , , , , , , , , , , , , , , , </del>			 
6	GANIZ/ NANCE	<i>iς</i> ) 21-50				<del></del>										 
	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(b) 6-20														 
		(a) 1.5														
(9)	ON N TΩN N		3	9	-	Ω		e e	е	9	12		#			
(5)	ÇNZ Z	PACK														
(4)	DE 1220E		EA	EA	ΕA	EΑ	EA	EA	EA	EA	EA		ΕA	EA	EA	
		USABLE ON CODE														
(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE	PLUG ASSEMBLY, DUST SX1617 (88795)	CHAIN ASSEMBLY, SINGLE H6682M (81718)	PLUG, HOSE 634A (81718)	COUPLING HALF, QUICK 633E (81718)	CAP ASSEMBLY, DUST SX1604 (88795)	САР, HOSE 634В (81718)	CHAIN ASSEMBLY, SING LE H6682M (81718)	GASKET H6 <sup>4</sup> 30M (81718) (INITIALLY LISTED AS INDEX NO. 00189)	ring, finger sx1605 (88795)	2210 - DATA PLATES AND INSTRUCTION HOLDERS	DRIVE SCREW BHOOZA (88795)	IDENTIFICATION, PLATE G3020A2 (88795)	PLATE IDENTIFICATION; CYLINDER SHIELD 220478 (08645)	
(2)	FEDERAL STOCK			4010-628-5276	4730-595-3846	4730-542-4030		4730-555-1562	4010-628-5276	4730-360-0595				-	2930-537-1364	
ĉ	SMR CODE	INDEX NO.	×1 00190	x 00191	x1 00192	х1 ∞193	x 100 194	x1 00195	x1 00196	P 0 00197	x1 ∞198	00199	X20 00200	X20 00201	x20 00202	 

10   10   10   10   10   10   10   10	(8) LUS-	(b)	NO.					8				23	Kr .	_	7	22	
EA 1 1 EA 1 1 E EA 1 E EA 1 E EA 1 1 E EA 1 E EA 1 1 E EA 1 E EA 1 E E EA 1	<u>ר</u>	(a)						12				22	72	2	22	5	
EA SABLE ON CODE    CABLE ON CODE   CABLE ON		IONAL ALW															
USABLE ON CODE  USABLE ON CODE  EA E E E E E E E E E E E E E E E E E	6	ANIZAT	(c) 21-50		.,,,,,		·										
USABLE ON CODE  USABLE ON CODE  EA E E E E E E E E E E E E E E E E E	_	Y ORG	(b) 6-20														
USABLE ON CODE EA E EA EA DAIT OF ISSUE (*)  EA E EA		15-DA	(a) 1-5														
USABLE ON CODE EA	9	Ç≅ Z∪Z	CNIT			_		-	_	_	2	-	m	_		_	
USABLE ON CODE	ହ	Ç <u>≅</u> ≅	PACK			•											
	E &	DE 1220	D TINU	*		EΑ	¥.	EA	ΕÀ	EA	EA	EA.	EΑ	EA	ξA	EA	
GROUP 72 - DISPENSING AND SERVICING EQUIPMENT COMPONENTS 7202 - PUMPS AND METERS  PUMP ASSEMBLY SX1603 (88795) (INCLUDES COMPONENTS OF KIT, STOCK NO. 4320-989-3259) (ASSEMBLY SX1604 (88795) CARING ASSEMBLY SX1604 (88795) CARING ASSEMBLY SX1604 (88795) CARING SSEMBLY SX1604 (88795) CARING SSEMBLY SX1604 (88795) CARING SSEMBLY SX1604 (88795) CARING SX1604 (88795) CARING SX1604 (81718) FINGER, RING SX1605 (88795) COUPLING, HALF QUICK; PUMP CASING 633F (81718) ELBOM, SIDE OUTLET, PUMP; ALL ENOS FEMALE, 11/2-11 1/2 THO SIZE SX990 (88795) HANDLE, PUMP CZOCZA1 (88795) NIPPLE: 11/2 IN, ALUM, 2 IN LG PUMP CASING SX715 (88795)			USABLE ON CODE														
	(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE	GROUP 72 - DISPENSING AND SERVICING EQUIPMENT COMPONENTS	7202 - PUMPS AND METERS	PUMP ASSEMBLY SX1603 (88795) (INCLUDES COMPONENTS OF KIT, STOCK NO. 4320-989-3259)	CASING ASSEMBLY SX1608 (88795)	CAP ASSEMBLY, DUST SX1604 (88795)	САР 634в (81718)	CHAIN ASSEMBLY, SINGLE SECURITY H6682M (81718)	FINGER, RING SX1605 (88795)	_			HANDLE, PUMP C2002A1 (88795)		
(1) (1) (20 CODE  (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE) (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE) (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE) (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE (20 CODE)	(2)	FEDERAL STOCK		<del> </del>	D0203A				4730-555-1562	4010-628-5276		4730-360-0595	4730-805-6726				

										da mayo kar imiliya wa				was the state of		Marine and the same of the
(a) (b)	NO.	₹.	21		8	5	21	<b>T</b>	6	<u>8</u>	13	5		عبر سندان استثنا		
TRA 184	FIG NO.	12	12	12	12	12	5	12	12	72	. 22	12				
ONAL	(4) 51-100									-				*		
(7) 15-DAY ORGANIZATIONAL MAINTENANCE ALW	(c) 21-50													*		
Y ORGA	(b) 6-20													*		
15-DA MA	(a)													*,		
E TON Z	ב <u>ו</u>	, a			_	<i>A</i>	_	A	5	_	2	<i>A</i>		N	-	
E TON	PACK															
F 18SUE		EA	Ľ.	EA	EA	ă	EA	Ğ	EA.	EA	EA	EA	\$-	ΕA	Z.	
(3) DESCRIPTION	REFERENCE NO. 8, MFR. CODE USABLE ON CODE	NUT, CAP: PUMP CASING, 3/8-16 THD SIZE BG001A2 (88795)	PLUG, PIPE: 1/2 IN NPT PUMP CASING AJOOZAH (88795)	ADAPTER ASSEMBLY SX1609 (88795)	BOLT: PUMP MTG, 5/16-18 THD SIZE, 5/8 IN LG BEOOZAZ (88795)	BOLT: PUMP TO ENGINE MTG, 5/16-24 THD SIZE, 3/4: IN LG BEO01A3 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZA5 (88795)	NUT, HEXAGON: PUMP ADAPTER MTG, 3/8-16 THD SIZE BGOO2B3 (88795)	NUT, HEXAGON: PUMP MTG, 5/16-18 THD SIZE BGOOZBZ (88795)	WASHER, FLAT; PUMP MTG, 5/16 IN SCREW SIZE ADOOIA1 (88795)	WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOO281 (88795)	WASHER, LOCK: PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZBZ (88795)	7203 - VALVES, FITTINGS, NOZZLES	NOZZLE ASSEMBLY, NONAUTOMATIC SX931A (88795)	COUPLING, HALF, QUICK 6338 (81718)	
(2) FEDERAL STOCK	NUMBER		*											4320-946-9961	4730-715-1558	
	INDEX NO.	x20 00217	x20 00218	x20 00221	x20 00224	x20 00225	x20 00226	x20 00228	x20 00229	x20 00230	x20 00231	x20 00232	96200	P 0R 00239	χ20 00241	<u> </u>

	Z 3				<del></del>	m	2		0	2	6	9	∞			2		
(8)	TRATION (b)		20.		13 11		13	<u>ي</u>	13_	£.	<del>ا</del>	13	<del>ي</del>			5	15 1	
		9	8														8	
	ZATION E AL	(3)	0				· · · · · · · · · · · · · · · · · · ·										#	
(7)	PENANC	(9)		<del></del>	·			-									2	
	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(0)															2	
(9)	NOTY IS	丄	_					_	~	<del>-</del>	-	_	<u>-</u>			_	2	
(2)	YUN	<u> </u>	ACK					<del></del>						<del></del>		<del></del>		
	- 250 : 122∩E			EA	EA	EA.	EA	EA	EA	EA	EA	EA	EA		EA	EA	EA	
Ť												ш			_ ш	_ш	Ш	<b>!</b>
			ON CO					•										Ì
			USABLE ON CODE															
			ח															
<u>(5)</u>	DESCRIPTION						6							v				
182	DESCRI						INDEX NO. 00189)							AND ACCESSORIES				
							EX No.							ACCES	₹			
			DE							Ξ.		MBLY 1718)	ರ		100			
			F. CO	ST	ž		GASKET HG <sup>L</sup> 30M (81718) (INITIALLY LISTED AS			SO MES	찙	K ASSE /8 (8)	OUND IA	S PART	09 <b>-</b> 0	Æ		
			O. & ME	Y, Du. (795)	CHAIN, BRASS: 6 1N H6682M (81718)	18)	718) 718)	. 6	ER 795)	ER: 1(	NG VIII	NOZZLI	Υ, 8)	ANEOUS	10-NG (235)	100 G 795)	TER 0005)	
			NCE N	SSEMBL 17 (86	, 88. ≥ (81	COUPLER SX888 (81718)	OM (81	PLUG, DUST 634A (81718)	RING, FINGER SX1605 (88795)	F1LT (81718	10ND0 84 88) 84	1910; 5 1 1/	SSEMBL (8171	SCELL	IMBLY,	END:	1, FIL	
			REFERENCE NO. & MFR. CODE	PLUG ASSEMBLY, DUST SX1617 (88795)	CHA11 H668;	SX888	GASKE H6½3( ( ) .	PLUG, 634A	SX16	SCREEN, FILTER: 100 MESH 153 (81718)	SCREW, GROUNDING WIRE SX1048 (88795)	SPOUT, RIGID; NOZZLE ASSEMBLY CC296 1 1/2X1 5/8 (81718)	WIRE ASSEMBLY, GROUNDING 190W (81718)	7204 - MISCELLANEOUS PARTS	GAGE_ASSEMBLY, 10-NO-GO: 100 GPM SX1611 (887.5)	ccver, end: 100 GPM SX1613 (88795)	ELEMENT, FILTER 041420S (90005)	
			~	0.						· ν	SCR	SPO	3	720	GAG			
	3AL	ξ R					0-0595	5-3846									2-1779	
(2)	FEDERAL	NUMB					<sup>4</sup> 730-360-0595	4730-595-3846									4930 <b>-</b> 872-1779	
ε	SMR CODE	X	NO.	X20 002 <sup>μ</sup> 3	х20 00244	x20 00245	P 0 47	x20 00247	χ20 00248	х1 00249	x20 00250	x20 00251	x20 00252	00253	X20 00254	x1 00256	P 0 49	1
L	٠,٥	1 2	<u> </u>	L %8	8 %	8 %	<u> </u>	8%	88	<u>×8</u>	8%	%8	8%	8	28	× 8	48	13

			<del>'</del>					<del></del>								-			
(8) LUS-	TRATION (a) (b)	IT EM NO.	77		80	2	4			<u>е</u>		0	12	6	7	_	=		
	(a)	NO.	7.		<b>≉</b>	<b>₹</b>	7.			<u>7</u>		7	<u>,</u>	<b>2</b>	<u> </u>	<b>₹</b>	#		
	NAU ALW	(4)										~				*			
(1)	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(c) 21-50		J								*				*			
	Y ORGA INTENA	(a)	3	ı								*				*			
	15-DA MA	(0)	*									*				*			
9)	Çŏ⊼ Zor	E S			N	N,	Ω.	2	<b>A</b>	CV .	7	.≠		-	· <b>-</b>	ά	-		
(5)	Ç N V V V V	PACK																	
€ 3	INSSI 3	טאוד כ	٠ ٨	5	EA	EA	EA	EA	EA	EA	EA	EA	EA	EA	EA	EA	Ε¥		
(3)	DESCRIPTION	REFERENCE NO: 8 MFR. CODE		MS29513-249 (96906)	ADAPTER, HOSE MAB6 (88795)	ADAPTER, HOSE: 1 1/2 IN · 633F (81718)	CAP ASSEMBLY, DUST SX1604 (88795)	DUST CAP 634B (88795)	FINGER RING SX1605 (88795)	GASKET HG430M (81718) (Initially Listed as Index No. 00189)	CHAIN, ASSEMBLY, SING HGG82M (81718)	CLAMP, HOSE QS200M28A (88795)	COUPLER: 1 1/2 in 633H (81718)	HOSE, GAGE CONNECTING SX1619 (88795)	NIPPLE: 1 1/2, ALUM, 2 IN LG SX715 (88795)	GAGE, PRESSURE, DIAL 022-171 (38508)	PLUG ASSEMBLY, DUST SX1617 (88795)		
(2)	FEDERAL STOCK		5330-526-7517	1101-050-050		4730-805-6726				4730-360-0595	4010-628-5276	1320-920-53µ2	4730-020-9293			101-826-9899			
€	SMR	NDEX NO.	5	00259	X20 00260	x20 00261	x1 00262	x1 00263	X1 00264	P 0 00265	x1 00266	P 0 00267	x20 00268	x20 00269	x20 00270	P 0 00271	x20 00272	-	

(8) LUS-	TRATION (a) (b)	ITEM NO.	1	m				
= 1	(a)	FIG NO.		<b>7</b>			켣	
	ONAL ALW	(4)						
(0)	15-DAY ORGANIZATIONAL MAINTENANCE ALW	(c)						
0	ORGA NTENA	(e)						
	15-DA MAI	(0)		4				
9	ŽŲZ Z	EN S	2		-	7-		a
35	ŽŮZ Z		÷					
€ 3	I I 2201	O TINU	EA	ĘĄ	EA	ξ¥	EA	
		USABLE ON CODE						
(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE	FINGER RING SX1605 (88795)	GASKET HG430M (81718) (INITIALLY LISTED AS INDEX NO. 00189)	PLUG, HOSE 634A (81718)	CHAIN ASSEMBLY, SINGLE H6682M (81718)	TEE, ALUM: 1 1/2, 1/2 X 1/2 SX733 (88795)	
(2)	FEDERAL STOCK	NOMBER	-	4730-360-0595	4730-595-3846	4010-628-5276		
ε	SMR CODE	NDEX NO.	X1 00273	P 0 00274	x1 00275	x1 00276	x20 00277	

	JS- 10N	(b)	NO.				ω									9		
Ê	ILLUS- TRATION	(0)	NO.															
(01.)	DEPOT MAINT	AL#- PER- 100	EQUIP					15	25									
6)	A W R	EOUIP ONTGCY						瓦	<i>1</i> 2									
		<u> </u>	51-100					2	N									
3-DAY	GS MAINT ALLOWANCE	(a)	50					N.	N									
(8)	GS ALL	(e)	1-20 21					*	7									
	T NCE	(0)	51-100					7	2	4050	0301	0101	0101	9050	GRP 0106			
10 - DAY	DS MAINT ALLOWANCE	લ	21-50					2	٧	GRP	GRP	GRP	GROP	: GRP	1.1		-1	
(2)	c ₹	(0)	1-20					*	2	SE	338	SEI	SE	SE	SE			
(9)	ΑΤΟ NO	N N	,				#	-	-	-	-	-	-	-	-	A	#	
151	NC Y	PACK														•		
G 3	IUSS!	40 T	חמו.				EA	EA	EA	EA	ΕA	Ę	£	EA	Ę	EA	EA	
(3)	DESCRIPTION		REFERENCE NO. & MFR. CODE USABLE ON CODE	SECTION V - REPAIR PARTS FOR DS, GS, AND' DEPOT MAINTENANCE	GROUP 01 - ENGINE	0100 - ENGINE ASSEMBLY	BOLT, MACHINE: ENGINE MTG, 5/16-18 THP SIZE 1 1/2 IN. LG BEOOZA7 (88795)	ENGINE: 3 HP 81232 (08645)	GASKET SET: engine 297275 (08645)	GASKET; AIR CLEANER 27660 (08645)	GASKET: саявиветов мто 27402 (08645)	GASKET: CRANKCASE COVER MTG 27586 (08645)	GASKET: CYLINDER HEAD MTG 27670 (08645)	GASKET: FUEL TANK MTG 27911 (08645)	GASKET: VALVE CHAMBER BREATHER MTG 27549 (08645)	NUT, PLAIN, HEXAGON: ENGINE MTG, 5/16-18 THO SIZE BGOOZBZ (88795)	WASHER, LÖCK: ENGINE MTG, 5/16 in screw size AHOO2B1 (88795)	
(2)	FEDERAL	STOCK					w	2805-999-5238 E	2805-828-0783   6	2940-608-8514	2940-171-7935	2805-678-4432	2805-678-4395	2910-898-2094	2805-678-4431	_	3	
ε	CODE	NOEX NO		0000	00001A	00001B	X2F 00002	P F R 00003	0 d 40000	×1 00005	x1 00006	x1 00007	X1 00008	x1 00000	x 0000	X2F 00011	X2F 00012	

- <sup>2</sup> 20 NO	(b) ITEM	9				<b>4</b>	_	7	m	<i>A</i>	<u>ι</u> ν	91	22	7	6
(11) ILLUS- TRATION	(a) FIG	ON N			7	0,	6	~	N	_	_	N	0	6	_
(10) DEPOT MAINT	ALW- PER 100										8	82		2	
(y) 1-YR ALW PED	100 EQUIP CNTGCY										80	8,	•	2	
r T ICE	(c)	51-100									N	0		*	
30-DAY GS MAINT ALLOWANCE	(q)	21. 50	-,								α	64		*	
(8)	(e)	51-100 1-20					<del></del>				*	*		*	
Y VNCE	(2)	21-100					***************************************				8	0		*	
30-DAY DS MAINT ALLOWANCE	3	1-20 21-50	·				************************				N	2		*	
<u>د</u>	<u>(5)</u>	1-20		-							*	*		*	
(8) Y	Z Z Z				9	<u>ب</u>	m	<del>-</del>	-	-	-	-	-	_	-
(S)	UNIT PACK														
€ ∃USS	я <b>о</b> т	ואט			Ε¥	EA	EA	EA	EA	EA	Ε¥	EA	E	EA	۲
(3) MACABIDANA	DESCRIPTION	REFERENCE NO. & MFR. CODE USABLE ON CODE		0101 – CRANĶCASE, BLOCK, CYLINDER HEAD	BOLT, ASSEMBLED WASHER: CRANKCASE COVER MTG 93032 (08645)	BOLT, MACHINE: CYLINDER HEAD MTG, 5/16-18 THD SIZE, i 15/16 in Lg 93111 (08645)	BOLT, MACHINE: CYLINDER HEAD MTG, 5/16-18 THD SIZE, 2-5/16 IN LG 93113 (08645)	COVER, CRANKCASE 294306 (08645)	GASKET: CRANKCASE COVER MTG 27586 (08645) (COMPONENT OF GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP 0100)	CYLINDER ASSEMBLY 296610 (08645)	SEAL, OIL, PLAIN ENCASED: CRANKSHAFT 89660 (08645)	SEAL, OIL: CRANKCASE COVER 293740 (08645)	GASKET: CYLINDER HEAD MTG 27670 (08645) (COMPONENT OF GASKET SET, STOCK NO. 2805-828-0783, SFE GROUP 0100)	HEAD, CYLINDER 210812 (08645)	PLUG, PIPE; OIL DRAIN 91249 (08645)
(2) FEDERAL	STOCK							2805-658-3916	2805-678-4432	2805-920-5383	2805-351-6692	2805-624-0278	2805-678-4395	2805-594-1030	4730-950-7613
	N N N N N N N N N N N N N N N N N N N		I	poc13	X2F 00014	X2F 00015	x2F 00016	X2F 2	X1 00018	X2F 00019	P F 20000	P F 2	X1 00022	P F 2	F b

NAMER   REFERENCE NO. 1 AFR. CODE   USABLE ON CODE   F. DACK   UNIT   N. P.	SK 3	(2) FEDERAL	(3) Descentance	₹ anss	(S)		(7) DS ALI	30-DAY DS MAINT ALLOWANCE	<u> </u>	30-DAY GS MAINT ALLOWANCE	₹CE	(7) 1-YR ALW	(10) DEPOT MAINT	(11) ILLUS- TRATION	78
S15-276-k06    PIN, STRAIGHT, HEADLESS; CHANGAT VALVE   EA	NO.	STOCK	מבארות המי	1 OF 1	NIN PACK	Z Z Z	(0)		=	(9)	(c)	PER 100 EQUIP CNTGCY	ALW- PER 100 FOLUP		(b) TEM
1315-276-4061 PIN, STRAIGHT, FEALESST EXHAUST VALVE  1316-246-0059 PIN, STRAIGHT, FEALESST EXHAUST VALVE  1316-246-0059 PIN, STRAIGHT, FEALESST INTAKE VALVE  1316-246-0059 PIN, STRAIGHT, FEALESST INTAKE VALVE  1316-246-0059 PIN, STRAIGHT, FEALESST INTAKE VALVE  1316-246-1394 SEATH VALVE SPRINGST VALVE  1316-348-1370 SPRING, FELLOAL STRAIGHT VALVE  1316-36-313-1370 SPRING, FELLOAL STRAIGHT VALVE  1316-36-313-313 SPRING, FELLOAL STRAIGHT VALVE  1316-36-313-313 SPRING, FELLOAL STRAIGHT VALVE  1316-36-313-313 SPRING, FELLOAL STRAIGHT VALVE  1316-313-313 313-313-313-313-313-313-313	1			NU			1-20 2	1-50 51-	100	5	22				9
SBO-592-793  Returner, Emaile (19645)   SPRINGE, FURLER, EMAILE (19645)   SPRINGE, ELICAL, COMPRESSION, EMAILE WALE   SBO-592-0403   SPRINGE, ELICAL, COMPRESSION, INTAKE WALE   SBO-592-0403   SPRINGE, EMAILE, WALE   SBO-502-0403   SPRINGE, EMAILE, WALE   SBO-502-0403   SPRINGE, WALE, WALE   SBO-502-0403   SPR		5315-276-4081	PIN, STRAIGHT, HEADLESS: EXHAUST VALVE 230126 (08645)	E		<b>-</b>	*					, rv	2		<u>.</u>
2805-372-1793         GEAL HURS, CHANGER, CAMPRESION, INTAKE WALE         EA         1         *	P F 00040	5315-248-0052	PIN, STRAIGHT, HEADLESS: INTAKE VALVE 23187 (08645)	<b>T</b>		<del>-</del>	*				*	5	2		12
2805-342-7432         Serial Rotator cap. Exhaust valve         EA         1         *<		2805-353-7587	RETAINER, EXHAUST VALVE 230127 (08645)	<b>T</b>		-	*	· · · · · · · · · · · · · · · · · · ·	٠.		*	7	7		4
2805-296-133h         SERING, INTAKE         SERING, INTAKE         CARRESSION, EXHAUST VALVE         EA         1         * </td <td>P F 2</td> <td>2805-342-7432</td> <td>ROTATOR CAP, EXHAUST VALVE 292259 (08645)</td> <td>EA</td> <td></td> <td><b>,-</b></td> <td>*</td> <td></td> <td></td> <td></td> <td>8</td> <td>2</td> <td>2</td> <td>-</td> <td>15</td>	P F 2	2805-342-7432	ROTATOR CAP, EXHAUST VALVE 292259 (08645)	EA		<b>,-</b>	*				8	2	2	-	15
2805-529-0403 SPRING, HELICAL, COMPRESSION, EXHAUST VALVE  EA 1 * 2 2 * 2 2 2 20 20 1  EA 1 * 2 2 * * 2 2 2 2 20 20 1  EA 2 2 * * 2 2 2 2 20 20 1  EA 2 2 * * * * * * * * * 5 2 2 2 20 1  EA 2 2 * * 2 2 2 2 2 2 2 2 2  EA 2 2 * * * * * * * * * 5 2 2 2 2 2  EA 2 2 * * * * * * * * * 5 2 2 2 2 2  EA 2 2 * * * * * * * * * 5 2 2 2 2 2  EA 2 2 * * * * * * * * * 5 2 2 2 2  EA 2 2 * * * * * * * * * 5 2 2 2 2  EA 2 2 * * * * * * * * * 5 2 2 2 2  EA 2 2 * * * * * * * * * 5 2 2 2  EA 2 2 * * * * * * * * * * 5 2 2 2  EA 2 2 * * * * * * * * * * 5 2 2  EA 2 2 * * * * * * * * * * * 5 2 2  EA 2 2 * * * * * * * * * * * 5 2 2  EA 2 2 * * * * * * * * * * * * * 5 2 2  EA 2 2 * * * * * * * * * * * * * * * * *	P F 000 <sup>‡</sup> 3	:805-356-1334	SEAT, VALVE SPRING: INTAKE 23184 (08645)	EA		-	*			*	*	· .	2	_	Ξ
SPRING, HELICAL, COMPRESSION, INTAKE VALVE  260552 (08645)  TAPPET, VALVE 233173 (08645)  VALVE, EXHAUST 296676 (08645)  VALVE, INTAKE 296677 (08645)  O106 - ENGINE LUBRICATION SYSTEM  BOLT, ASSEMELED WASHER; BREATHER WITE  BOLT, ASSEMELED WASHER; BREATHER WITE  BREATHER, VALVE CHAMBER  CAP, OIL, FILLER; CRANKGASE COVER  CAP, OIL, FILLER; CRANKGASE COVER  EA	P F 2	:805-254-1370		E.		_	*			~	N		8	~	16
2805-678-4425 TAPPET, VALVE 23-3173 (08645) 2805-920-5388 VALVE, EXHAUST 2805-920-5388 VALVE, EXHAUST 2805-920-5388 VALVE, EXHAUST 2805-920-5388 VALVE, EXHAUST 296676 (08645) 296676 (08645) 296677 (08645) 296677 (08645) 296677 (08645) 296678 SEEFINE LUBRICATION SYSTEM 3966-073-8255 297178 (08645) 297178 SEEFINE VALVE CHAMBER 29678 CAP, OIL FILLER; CRANKCASE COVER 297178 (08645) 297178 (08645) 297178 (08645) 297178 SEEFINE CAP, OIL FILLER; CRANKCASE COVER 297178 (08645) 297178 (08645) 297178 (08645) 297178 SEEFINE CAP, OIL FILLER; CRANKCASE COVER 297178 (08645) 297178 SEEFINE CAP, OIL FILLER; CRANKCASE COVER 297178 (08645) 297178 SEEFINE CAP, OIL FILLER; CRANKCASE COVER 297178 SEEFINE CAP, OIL		:805-992-0403		EA.			*			~	8	8	02	_	9
2805-920-5388         VALVE, EXHALST         EA         1         *         2         2         *         2         15         15         11         11         *         *         2         *         *         2         15         15         11         11         *		:805-678-4425	TAPPET, VALVE 233173 (08645)	¥3		~	*			*	*	<u>بر</u>	2	-	
2805-018-5293 VALVE, INTAKE 296677 (08645)  0106 - ENGINE LUBRICATION SYSTEM  0106 - ENGINE LUBRICATION SYSTEM  3306-073-8255 BOLT, ASSEMBLED WASHER: BREATHER WIG 29334 (08645) 2805-624-0282 BREATHER, VALVE CHAMBER 294178 (08645) 2805-422-5804 CAP, OIL FILLER; CRANKGASE COVER  EA 1 * * * * * * * * * * 5 5 5 1		:805-920-5388	VALVE, EXHAUST 296676 (08645)	EA		<b>,-</b>	*			67	٧	12	15	_	7
0106 - ENGINE LUBRICATION SYSTEM 5306-073-8255 BOLT, ASSEMBLED WASHER: BREATHER WTG 93394 (08645) 2805-624-0282 BREATHER, VALVE CHAMBER 294178 (08645) 2805-422-5804 CAP, OIL FILLER: CRANKCASE COVER EA 1 * * * * * * 5 5 5 1	-o'~	:805-018-5293	VALVE, INTAKE 296677 (08645)	ΕĶ		<u></u>	*			*	N	2	2	-	9
5306-073-8255 BOLT, ASSEMBLED WASHER: BREATHER HTG 93394 (08645)  294178 (08645)  294178 (08645)  29505-422-5804 CAP, OIL FILLER: CRANKCASE COVER  EA 1 * * * * * 5 5 5 1			0106 - ENGINE LUBRICATION SYSTEM												
2605-624-0282       BREATHER, VALVE CHAMBER       EA       1       *       *       *       *       *       *       5       5       5       5       5       5       5       1         294178       (08645)       (08645)       EA       1       *       *       *       *       *       *       5       5       2       1		306-073-8255	HER	EA		2							· ·	5	∞
2805-422-5804 CAP, OIL FILLER: CRANKCASE COVER 69345 (08645)		805-624-0282	BREATHER, VALVE CHAMBER 294178 (08645)	EA		-	*			*	*	5	5	5	<b>#</b>
		805-422-5804	CAP, OIL FILLER; CRANKCASE COVER 69345 (08645)	Ε <b>A</b>		-	*			*	*	2	2	~	=

	۶ <u>۶</u>	3	NO	·	Δ.		12	9			16	2	70	11	9	6	5
î.	ILLUS- TRATION	(0)	- ON	IV.	70	7	N	<u> </u>			<b>A</b>	#	#	#	#	#	<b>A</b>
(10)	DEPOT	ALW-	SOUIP SOUIP		ಜ			5		2							5
(6)	1-YR E	PER	NTGCY		8			2		9				<del></del>			5
,		-	51-100					*		~							*
0-DAY	GS MAINT	(a)	5		8			*		*							*
(8)	. S. <u>-</u>	[] []	1-20 21		7			*		*			~~~				*
$\overline{}$	ند ر 1 – Ž	(3)	51-100		m			*		N							*
30 DAY	DS MAINT	3	21.50		2			*		*							*
(2)		3	120		2			*		*							*
(9)	QTY	ZZZ	5	-		-	-	-		<b>-</b>	9	-	-	-	-	<del>-</del>	
151	ν. ΣΤΑ	Z Z Z	PACK														
G. :	3∩\$	\$' ±0	TINU	ΕA	Ε <b>A</b>	ΕA	EA	EA		EA	ΕA	Ę	ΕA	Ε¥	EA	EA	EA
(3)		DESCRIPTION	REFERENCE NO. & MFR. CODE USABLE ON CODE	GASKET: VALVE CHAMBER COVER MTG 27549 (08645) (COMPONENT OF GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP 0100)	GROMMET; BREATHER COVER 66578 (08645)	GROMMET, BREATHER TUBE 67608 (08645)	NIPPLE, PIPE; OIL FILLER, 3/4 IN, 2 IN LG 91258 (08645)	тиве, вкедтнек 230634 (08645)	0107 - ENGINE STARTING SYSTEM	CLUTCH ASSEMBLY STARTER 298310 (08645)	ВЕАRING, ВАLL: сгитсн ноизтис 63770 (08645)	BUMPER, STARTER PULLEY 66528 (08645)	GRIP, ENGINE STARTER 66728 (08645)	HOUSING, STARTER CLUTCH 211383 (08645)	PIN, STARTER GRIP 230228 (08645)	PULLEY, ENGINE STARTER 294088 (08645)	298436 (08645)
(2)	FEDERAI	STOCK	REFERE	2805-678-4431 GASKET: 2754 (COMPONE 2805-8	2805-776-2282 GROMMET:	GROWMET, 6766	4730-192-9481 NIPPLE,	2805-849-3141 TUBE, BE	0107 - 1	2990-907-0644 CLUTCH A	3110-100-6180 BEARIN 6377	5840=787=6662 BUMPEF	2990-768-0723 GRIP,	HOUSIN 2113	5315-855-4336 PIN, 8	2990-786-2030   PULLEY	2990–930–1737 RATCHE 2983
ε	38.5	INDEX	o S	x1 x1 x0053	P 0 28	x20 00055	95000	P 0 28	00058	P 0 29	x1 00000	x1 00061 58	x1 29	x20 00063	x1 00064 53	x1 29	P 0 29

(3)  REFERENCE NO. & MFR. CODE  ROPE, ENGINE STARTER: 47 1/8 IN LG 294584 (98645)  SCREW, REWIND STARTER PULL 221661 (08645)  SCREW, ASSEMBLED WASHER: SCREEN WTG 93042 (08645)  WASHER, CLUTCH RETAINER 221653 (08645)  WASHER, RUBBER, RATCHET SEALING 68236 (08645)  CAP. SPRING 221377 (08645)	E 5	(4)   (5)   (6)   (7)   30-DAY   (8)   30-DAY   (9)   (10)   (11)	PACK UNIT EQUIP 100 FIG 1 FIG 1 1-20 21-50 51-100 1-20 21 50 51-100	EA 1 4 8 17 4 8 17 200 200 14 2	1 12 12 12 12 12 12 12 12 12 12 12 12 12	11 A 11	EA1 * * 2 * * 2 10 10 14 3	4t t	13 13			EA 1 2 2 3 2 2 3 30 30 6 7	7 A	7 7	T 11	EA 1 2 2 3 2 2 3 30 30 7 5	EA 1 2 4 8 2 4 8 100 100 7 18
1 15 76 76 76 76 76 76 76 76 76 76 76 76 76		DE		ROPE, ENGINE STARTER: 47 1/8 294584 (08645)				WASHER, CLUTCH RETAINER 221653 (08645)	WASHER, RUBBER, RATCHET SEALING 68238 (08645)	GROUP 03 - FUEL SYSTEM	0301 - CARBURETOR				CRANK, BELL 297069 (08645)		

) St-	ž Ž	(b) ITEM	ջ		2	13	17	91	9		19		<b>≄</b>	<u>е</u>	9	- 2	15	9
(1)	TRATION	(a) F1G	Ö.	-			~	2	7		2-		_	7	_	7	~	9
(10)	MAINT	PER 100	EQUIP			ಜ		8			8		%	%				
6	ALW PFP	EQUIP CN TGCY				8		<u>8</u>			ಜ		ಜ	ಜ				
		(c) ·	51-100			m		ω			3		m	m				
30-DAY	LOWAN	(9)	21 50			ď		<i>#</i>			2		0	~				
(8)	٦ ٩	(0)	1-20		-	7		N			α.		O.	0				
	NCE	(د)	51-100			m		ω			М		ω	m				
30-DAY	LLOWA	(q)	21-50			α		<i>#</i>			~	•	~	~				
5		(n)	1–20			Ο.	- 4-	7			~		α	α·				
(9)	Y L	Z E			-	<del></del>	-		-	-	_	<del></del>	<b></b>	_	_	-	2	-
(5)	Ļυ.	UNI PACK																
E E	USS:	10 T	חמו.		EA	EA	ΕA	EA	EA	EA	Ę	EA	ΕA	EA	Ę	EA	EA	EA
(3)	MOLEGIAN	VESTA TION	REFERENCE NO. & MFR. CODE	•	LINK, THROTTLE 260563 (08645)	VALVE, NEEDLE 23433 (08645)	NUT, NEEDLE VALVE 230590 (08645)	PACKING, PREFORMED 65978 (08645)	PIN, DIAPHRAGM COVER 93265 (08645)	PIPE, FUEL, PLASTIC 296811 (08645)	SEAT, NEEDLE VALVE 230591 (08645)	SHAFT AND LEVER, THROTTLE: CARBURETOR BODY 297961 (08645)	SPRING, NEEDLE VALVE 26336 (08645)	SPRING, PUMP DIAPHRAGM 260455 (08645)	SPRING, THROTTLE LINK 260564 (08645)	SPRING, THROTTLE SCREW 260775 (08645)	WASHER, NEEDLE VALVE 22235 (08645)	GASKET; CARBURETOR HTG 27402 (OSGH5) (COMPONENT OF GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP 0100)
(C)	FEDERAL	STOCK				2910-893-5072	2910-949-2135	5330-924-0049	5315-924-0051		2910-920-5363	2910-893-5073	5340-923-9875	5340-923-7050				29 <sup>4</sup> 0–171–7935
ε	SMR	NOEX	ż		X2F 00081	P F 00082	X2F 00083	P F 00084	P 00085	x1 00086	P F 00087	x1 00088	P F 00089	P F 000090	X2F 00091	X2F D0092	K2F D0093	×1 2009¥

Scrietly, ASSPREID WASTER; caresuretors to fruet.  Scrietly, ASSPREID WASTER; caresuretors to fruet.  Scrietly, ASSPREID WASTER; caresuretors to trainer with a state of state	NO.		REFERENCE NO. & MFR. CODE	USABLE ON CODE	) TINU	PACK UNIT		1-20	21-50 51-100		1-20 21	50 51-100	EQUITO CNTG	CNTGCY 100	FIG	TEM
SCREW, ASSENCE OF ASSENCE OF A STATE OF A	$\vdash$				<u> </u>		T		<del>  -</del>				-	<u> </u>	<u> </u>	
SCREY, CARCH RELL CRAIN HTG  SCREY, CAP, HEADON HEAD: CAROLNETOR TO EMBIRE HTG  1/A, 20 THO MILE AND HEAD: CAROLNETOR TO EMBIRE HTG  SCREY, MACHINE THROTTLE: SPECE AGUISTING  SCREY, MACHINE THROTTLE: THROTTLE: SPECE AGUISTING  SCREY, MACHINE THROTTLE: THROTTLE: THROTTLE: THROTTLE: THROTTLE: THROTTLE: THROTTLE: THROTTLE: TH	x20 00095		^		<b>5</b>		m								9	12
SCREW, CAP, HEXAGON HEADS: CARBURGTON TO ENGINE WITE  1/1/20 THOUSE 11: 34 IN LG  5337 (08645)  5GREW, DIAPHRADA COVER  5GREW, DIAPHRADA COVER  5GREW, DIAPHRADA COVER  5GREW, DIAPHRADA COVER  5940-294-1599  5GREW, DIAPHRADA COVER  5940-294-1599  664-7912  FILTER ELLEWER, INTAKE  5940-668-8714  668-7912  FILTER CLEANER, INTAKE  5940-668-8714  668-7912  FILTER CLEANER  674  1 * * * * * * * * * * * * * * * * * *	X2F 00096		SCREW: BELL CRAN, MTG 230671 (08645)		EA		_									12
SCREY, DIAPHRAGN COVER  SCREY, MACHINE, THROTILE: SPEED ADJUSTING  SCREY, MACHINE, THROTILE: SPEED ADJUSTING  SCREY, MACHINE, THROTILE: SPEED ADJUSTING  SQ90 – AIR CLEANER, INTAKE  2940–294–1599  AIR CLEANER, INTAKE  2940–608–7912  FILTER ELEMENT, AIR INTAKE  2950–608–7914  CASKET SET, STOCK NO. 2805–828–0783,  SCREY, AIR CLEANER  SCREY, AIR CLEANER  SCREY, AIR CLEANER  SCREY, AIR CLEANER  TAWK, FUEL  TAWK, FUE	x20 00097				<b></b>		~				- 0					2
SCREW, MACHINE, THROTTLE: SPEED ADJUSTING  93322 (08645)  O304 - AIR CLEANER  1	X2F 00098		SCREW, DIAPHRAGM COVER 93141 (08645)		EA		<b>A</b>								_	∞
0304 - AIR CLEANER, INTAKE 2940-294-1599 AIR CLEANER, INTAKE 2940-688-7912 FILTER ELEMENT, AIR INTAKE 27957 (08645) CLOMPONENT OF GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OF GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIOO) SCREW, AIR CLEANER 93322 (08645) COMPONENT OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIC GASKET SET, STOCK NO. 2805-828-0783, SCREW, AIR CLEANER 93322 (08645) SEE GROUP OIC GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP OIC GASKET SET, STOCK NO.	x2F 00099				E E	,	-								7	
2940-294-1599 AIR CLEANER, INTAKE 2940-688-7912 FILTER ELEMENT, AIR INTAKE 2940-688-7912 FILTER ELEMENT, AIR INTAKE 2940-688-7912 COMPONENT OF GASKET SET, STOCK NO. 2805-828-0783, 2940-608-8514 GASKET AIR CLEANER 2540-608-8514 GASKET SET, STOCK NO. 2805-828-0783, SEE GROUP 0100) SCREW, AIR CLEANER 93322 (08645)  O306 - TANKS, LINES, AND FITTINGS  TANK, FUEL 295591 (08645)  CAP, FUEL TANK 295591 (08645)  CAP, FUEL TANK 2953270 (08645)	00100		0304 - AIR CLEANER		, 1881							<del></del>				
29μα-688-7912         FILTER ELEMENT, AIR INTAKE         EA         1         *         2         2         *         2         2         2         2         *         2         3         3         3         3         4         3         3         4         3         3         4         3         3         4         3         3         4         3         3         3         4	P 0 294	40-294-1599	AIR CLEANER, INTAKE 294870 (08645)		E A	<del> </del>	_	*	*	*	*			- 5	9	8
2940-608-8714       GASKET: A.IR CLEANER         27600 (08645)       (Component of GASKET SET, Stock No. 2805-828-0783, SEE GROUP 0100)         SCREW, AIR CLEANER       EA       1       1       1       1         93322 (08645)       0306 - TANKS, LINES, AND FITTINGS       EA       1		10-688-7912	FILTER ELEMENT, AIR INTAKE 27987 (08645)		EA		-	*	~	~	*	·		50	9	e e
SCREW, AIR CLEANER 93322 (08645) 0306 - TANKS, LINES, AND FITTINGS  TANK, FUEL 295591 (08645) 2910-7703 CAP, FUEL TANK 295370 (08645) EA 1 * * 2 * * 2	х1 00103-	10-608-8514	GASKET; AIR CLEANER 27600 (08645) (COMPONENT OF GASKET SET, STOCK NO. 2805-828-0 SEE GROUP 0100)		E A		<del>-</del>								9	<i>A</i>
0306 - TANKS, LINES, AND FITTINGS  TANK, FUEL 296591 (08645)  CAP, FUEL TANK 293270 (08645)	X20 00104		SCREW, AIR CLEANER 93322 (08645)		<u> </u>		_								9	-
2910-707-7503 CAP, FUEL TANK 295270 (08645) EA 1 * * 2 * * 2	20105					·····										
2910-#07-7503 CAP, FUEL TANK 293270 (08645)	20 0106		TANK, FUEL 296591 (08645)	4						<del></del>					9	6
		10-707-7503	CAP, FUEL TANK 293270 (O8645)		EA		_	<del></del>						6	9	=

Γ	ı Z	(b)	202	- <del>-</del>	02			80	~	6	2	12	9	2	16		<b>*</b>
î.	ILLUS- TRATION		20 20 20 20	-	9			. 0	N	8	80	ω,	-	73	80	80	ω
L	لسسب		EQUIP		<u> </u>												
(6)	ALW N	FOUIP CNTGCY				<del></del>							· · · · · · · · · · · · · · · · · · ·	<del>• • • • • • • • • • • • • • • • • • • </del>			
		(2)	51-100														
30-DAY	GS MAINT ALLOWANCE	(q)	21 50														
(8)	A G	(0)	1–20														
<u>خ</u>	ANCE	16)	51-100												·	4.	
30 0.	DS MAINT ALLOWANCE	ङ्	2150														
(2)		[3]	1-20												1		
(9)		Z Z			-			-	-			-		-			-
(5)	Ž V V	PACK			·												
5 3	enss!	40 T	Ли.	EA	E A		¥.	EA	EA	Ę¥	EA.	EA	¥.	E .	EA	EA	EA
(3)	DESCRIPTION		REFERENCE NO. & MFR. CODE USABLE ON CODE	GASKET: FUEL TANK MTG 27911 (08645). (COMPONENT OF GASKET SET STOCK NO. 2805-828-0783 SEE GROUP 0100)	SCREW, CAP, HEXAGON HEAD: TANK MTG, 1/4-20 THO SIZE 93343 (08645)	0308 - ENGINE SPEED GOVERNOR	GOVERNOR ASSEMBLY 294932 (08645)	BODY, GOVERNOR 210227 (08645)	GEAR, GOVERNOR 210226 (08645)	SHAFT, GOVERNOR GEAR 230445 (08645)	BRACKET; control Rob mtg 221384 (08645)	BRACKET, MECHANICAL GOVERNOR; THROTTLE CONTROL 220691 (08645)	BUSHING: GOVERNOR LEVER 23688 (08645)	FOLLOWER, GOVERNOR CRANK 220381 (08645)	LEVER, GOVERNOR 294077 (08645)	LEVER, MECHANICAL GOVERNOR 220690 (08645)	LINK, GOVERNOR 260544 (08645)
(2)	FEDERAL	NUMBER		2910-898-2094			2990-992-0405					2990-787-6665	<u></u>	2805-679-5775 F	7		2990-920 <b>-</b> 5347 L
ε	CODE	NO.		x1 00108	X20 00109	00110	X2F 00111	X1 00112	x1 00113	X1 0011≱	x20 00115	x20 00116	X20 00117	X2F 00118	<b>X20</b> 00119	x20 00120	X20 00121

بل	, ĕ	(b)	Q Z	М	15	9	9	F	6	6	17	13	#	15	13	∞	72
	TRATION		o Z	<b>∞</b>	23	8	80	- ∞	2	ω	80	~	80	80	80	80	N
(10)	YAIN'	PER-	EQUIP										į	15	15		
(6)	ALW PER	100 EQUIP CNTGCY							,				15	15	15		
		( <u>.</u>	51-100	 		*							~	2	~		
30-DAY	OWANC OWANC	<u>a</u>	21 50 5										2	2	8		
(8)	AL S	(م)	1-20 2										*	*	*	***	
	NCE	ادر	51-100										7	8	N		
30. DAY	LLOWA	લ	21 50										2	2	2		
(7)		(a)·	1-20	 						···	<del></del>		*	*	*		······································
(9)		Z Z	_	-	-		-	-	7	_	<del>-</del>	-		-	-	2	-
(5)	ŽŲ.	PACK															
€ 3	nssi	яÓ 1	TINU	EA	EA	EA	EA	Ε¥	EA	EA	EA	EA	EA	EA	EA	ΕA	ξ¥
(3)	DESCRIPTION		REFERENCE NO. & MFR. CODE USABLE ON CODE	NUT, CONTROL ROD 230149 (08645)	PIN, STOP; GOVERNOR LEVER SHAFT 93043 (08645)	RETAINER, GOVERNOR SHAFT 230177 (08645)	ROD, CONTROL: GOVERNOR 230680 (08645)	SCREW, ASSEMBLED WASHER: BRACKET MTG, 10-24 THD SIZE, 9/16 IN LG 93062 (08845)	SCREW, CAP, SLOTTED: GOVERNOR MTG 93064 (08645)	SCREW, ASSEMBLED WASHER: THROTTLE LEVER MTG, 10-24 THD SIZE, 3/8 IN LG 93067 (08645)	SCREW, MACHINE: LEVER MTG 93100 (08645)	SHAFT, GOVERNOR LEVER 230181 (08645)	SPRING, CONTROL ROD 26855 (08645)	SPRING, GOVERNOR LEVER 260545 (08645)	SPRING, GOVERNOR LINK 260585 (08645)	WASHER: GOVERNOR BRACKET AND LEVER MTG 66432 (08645)	WASHER, FLAT: GOVERNOR LEVER SHAFT 22826 (08645)
(2)	FEDERAL	STOCK NUMBER			5315-626-1789	4805-679-5784			5305-753-4269	5306-543-5219	5305-719-4783	2910-711-5609	2990-624-0260	5340-945-0493	2990-898-2097		5310-353-7577
ε	CODE	S S S S	į	K20 20122	F 00123	K2F 00124	x20 00125	x20 00126	F 00127	00128	0 00129	X2F 00130	P 0 00131	P 0 00132	P 0 00133	X20 00134	ř 00135

		a ¥.0			9	17	77	0,	8	6	6	7	02	2	=	<u>м</u>
<u> </u>	3Ē  -	G TEM			6	6	0	0	<del>4</del>	6	#	6	6	0/	0.	σ.
	<u> </u>	PER 100 EQUIP FIG NO.			<u>س</u>				2	<del></del>	<u>e</u>	<u>~</u>		8		580
- 1	ALW MAI				ń				ις.	<del></del>	2	2		8		500
6	7				*				8	<u>m</u>	2	*		<del>-</del>		17
ΑΥ	ANCE	- 5			*				*	2	*	*		#		ω
30-05	ALLOWANCE.				*				*	8	*	*		~		#
8					*				8	<u></u>	~	*		<u></u>		
30- DAY	OWANCE	~			*				*	~~~	*	*		~ 	······································	8 17
	V V C	<del></del>	-		*				*	8	*	*		2		<b>*</b>
(6)	Y N N						-	-	<del></del>	_			<del>-</del>	-		<b>.</b>
		PACK														
		10 TINU 29.			EA	EA	EA	EA		EA		EA	EA	EA	EA.	EA
اد ز	1133: 2	10 11111			ш	ш	<del></del>	<u></u>	<u></u>	<u></u>			<del></del>		ш	ш
(2)	DESCRIPTION	REFERENCE NO. & MFR. CODE USABLE ON CODE	GROUP 06 - ELECTRICAL SYSTEM	0605 - IGNITION COMPONENTS	ARMATURE, MAGNETO 298502 (08645)	BOLT; condenser lead ntg 92786 (08645)	CLAMP: condenser mtg 260455 (08645)	cover, contact set 220366 (08645)	FLYWHEEL ASSEMBLY, MAGNETO 296884 (08645)	INSULATOR, PLATE: TERMINAL, CONDENSER LEAD 66935 (08645)	KEY, MACHINE: FLYWHEEL мТG 61760 (08645)	LEAD, ELECTRICAL, SPARK PLUG: ARMATURE 293141 (08645)	NUT, HEXAGON; CONDENSER LEAD MTG 90576 (08645)	PARTS KIT, IGNITION: BREAKER POINTS AND CONDEMSER 294628 (08645)	SPRING, HELICAL, EXTENDED: BREAKER ARM 26018 (08645)	PLUG, SPARK, WITH GASKET CJ8 (08645)
8	FEDERAL	NUMBER			2920-920-5373	5305-010-0752		2920-537-1365	2805-920-5385	5970-789-1925	5315-598-5970	2920-213-1147	5310-596-5224	2805-624-0284	5340-286-4566	2920-294-3747
												P 0 7				

Comparison   Com	ε	(2)	(3)	€ :	151	(9)	17)	-DAY	(8)	30	DAY	6)	(01)		=	
Sec-36-1333   Pulmer   Pulme	S C		INTEGRAL	anss		OTY	PS AL	MAINT		GS MA	INT	1-YR	DEPOT MAINT		-\ <u>\</u> 0	
PREFERENCE NO. & A.W.R. CODE   Justale On CODE   \$7   1   1   1   1   1   1   1   1   1	S S		DESCRIPTION			ZZZ	3	(9)	<u>  -</u>	9)	<u>0</u> .	T SEE	ALW 100	(e)	(b)	
290-356-1333   PLUMERIA, BREAKER POINT    EA   1   • • • 2   • • 2   10   10   9   13	į							1-50 51-		21.			EQUIP	S O.	Ş	
Signo-396-0340   Sirely, Assertier Declaration								-								
5305-719-4603   SCRM, ASSENGED WASHER: CONCENSER CLAMP NTO   EA   1   1   1   1   1   1   1   1   1	ь б 20161	2920-356-1333	PLUNGER, BREAKER POINT 65704 (08645)	EA		_	*		~	*			2	9/	5	,
5395-519-b603 Screw, ASSERBLD MASKER: concenses clave with the page (2004) (200	0 00162	5305-992-0440	SCREW, ASSEMBLED WASHER 93381 (08645)	Ę		, E								6	∞ .	
530-721-1467	0 00163	5305-719-4603	SCREW, ASSEMBLED WASHER: CONDENSER CLAMP MTO 93042 (08645)	ξ¥		_								6	4	
5310-721-4667   WASHER, FLATF, FLYWHELL HTG   220665 (00645)   WASHER, LOCK; condenser lead htg   5130-011-5944   WASHER, LOCK; condenser lead htg   5130-011-5944   WASHER, LOCK; condenser lead htg   520665 (00645)   WASHER, LECTRICAL; Lead, condenser to insulator   EA   1	00164	5305-543-5220	SCREW, ASSEMBLED WASHER: DUST COVER MTG 93014 (08645)	ď		~								9.	9	
5310-011-554   WASHER, LOCK! CONDENSER LEAD WITE   5190-624-0279   WIRE, ELECTRICAL! LEAD, CONDENSER TO INSULATOR   EA   1   9	0 00165	5310-721-4667	WASHER, FLAT: FLYWHEEL MTG 220865 (08645)	EA		-		, <u>1</u>			<del>-</del>			<i>*</i>	8	
S150-624-0279   WIRE, ELECTRICAL: LEAD, CONDENSER TO INSULATOR   EA   1	00166	5310-011-5544	WASHER, LOCK: CONDENSER LEAD MTG	E		7				<del></del>				9	92	
GROUP 15 - FRAME 1501 - FRAME ASSEMBLY SX1610 (88795)  BASE, LEFT SX16AA (88795)  BASE, RIGHT SX16AB (88795)  BASET, CARRYINS SX16AB (88795)  BASET, CARRYINS SX16AB (88795)  BOLT: SUPPORT AND SPACER NTG, 3/8-16 THD SIZE, 9 IN LG SX1094 (88795)  BOLT: SUPPORT AND SPACER NTG, 3/8-16 THD SIZE, 9 IN LG SX1094 (88795)  BOLT: SUPPORT AND SPACER NTG, 3/8-16 THD SIZE, 9 IN LG SX1094 (88795)	K20 00167	6150-624-0279		<b>5</b>		-								6	16	
1501 - FRAME ASSEMBLY	00168		GROUP 15 - FRAME			_			- <del></del>	<del></del>						
BASE, LEFT       EA       1       10       3         BASE, LEFT       SX16AH (88795)       EA       1       10       3         BASE, RIGHT       SX16AH (88795)       EA       1       10         BASE, RIGHT       SX16AH (88795)       EA       1       10         BASKET, CARRYING       EA       1       10         BASKET, CARRYING       EA       1       10         BACT: BASKET, CARRYING       EA       1       10         BACT: BASKET, CARRYING       EA       A       A       10         BACT: BASKET, CARRYING       EA       A       A       A       10         BACT: BASKET, CARRYING       EA       A       A       A       A       A       A       A       A         BEOCZAT (88795)       BACT: SUPPORT AND SPACER HTG, 3/8-16 THO SIZE, 9 IN LG       EA       2       A <td< td=""><td>00168A</td><td></td><td>1501 - FRAME ASSEMBLY</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>	00168A		1501 - FRAME ASSEMBLY													
BASE, LEFT       EFT       10         SXIGHA (88795)       EA       1       10         BASE, RIGHT       SXIGHB (88795)       EA       1       10         BASKET, CARRYING       EA       1       10         BOLT: BASK MTG, 5/16-18 THD SIZE, 1 1/2 IN LG       EA       1       10         BOLT: SUPPORT AND SPACER MTG, 3/8-16 THD SIZE, 9 IN LG       EA       2       10	x20 00169~		BASE ASSEWBLY SX1610 (88795)	E.		<del>-</del>										
BASKET, CARRYING SX1644B (88795)  BASKET, CARRYING SX700 (88795)  BOLT: BASE HTG, 5/16-18 THD SIZE, 1 1/2 IN LG BEOCZA7 (88795)  BOLT: SUPPORT AND SPACER HTG, 3/8-16 THD SIZE, 9 IN LG SX1094 (88795)	x20 00170		BASE, LEFT SX1644A (88795)	EA		-		••••••						2	m	
BOLT: SUPPORT AND SPACER WTG, 3/8-16 THD SIZE, 9 IN LG  SXTOO (88795)  BOLT: SUPPORT AND SPACER WTG, 3/8-16 THD SIZE, 9 IN LG  SX1094 (88795)  10	X20 0170A		BASE, RIGHT SX1644B (88795)	EA		-					<del>,</del>			02	m	
BOLT: BASE HTG, 5/16-18 THD SIZE, 1 1/2 IN LG  BEOOZAT (88755)  BOLT: SUPPORT AND SPACER HTG, 3/8-16 THD SIZE, 9 IN LG  SX1094 (88795)	x20 00171		BASKET, CARRYING SX700 (8795)	EA					•					9	ω	
BOLT: SUPPORT AND SPACER MTG, 3/8-16 THD SIZE, 9 IN LG EA 2 SX1094 (80795)	x20 00172			Ε¥		<b></b>								5	6	·
	x20 00173		size, 9	EA.		N								01	5	

•															
) SS- 10N	(b)	2	9	_	2	<b>A</b>	7						<b>~</b>	N	∞
(11) ILLUS- TRATION	(a) F (5)	j Z	01	0	9	10	10					11	=	=	Ξ
(10) DEPOT MAINT	ALW- PER 100 EQUIP										ī.	82			
(9) 1-YR ALW PEO	100 EQUIP CNTGCY										ľ	8			
	3	51-100									*	~			
30-DAY GS MAINT ALLOWANCE	<u>(a)</u>	21 50 5									*	N			
(8) 3 GS ALL	<u></u>										*	*			
	ري	51-100 1-20									*	8			
30DAY DS MAINT ALLOWANCE	(4)	1-20 21-50									*	N			
(/)	(0)	1-20									*	*			
(61 QTY INC	SER		<i>*</i>	~	2	2	<i>‡</i>			<u>-</u>	<del>-</del>	7	N	-	12
(5) QTY INC	PACK														
€ anssi	30. TII	NU	ΕA	ξ¥	EA	EA	ξ			EA	EA	EA	EA	EA	EA
(3) DESCRIPTION		REFERENCE NO. & MFR. CODE USABLE ON CODE	NUT, HEXAGON: BASE WTG, 5/16-18 THO SIZE BGOOZB2 (88795)	NUT, STOP: SUPPORT AND SPACER MTG, 3/8-16 THD SIZE SX989 (88795)	SPACER, BASE: 4-5/8 IN. LG SX988 (88795)	SUPPORT, FILTER ASSEMBLY SX1091 (88795)	WASHER, LOCK; BASE MTG, 5/16 IN SCREW SIZE AHOO2B1 (88795)	GROUP 22 - BODY CHASSIS OR HULL, AND ACCESSORY ITEMS	2202 - ACCESSORY ITEMS	ACCESSORY HOSE AND NOZZLE PACKAGE SX1077 (88795)	HOSE ASSEMBLY, SUCTION, RUBBER: WITH COUPLING SXCHB (88795) (COMPONENTS SAME AS HOSE ASSEMBLY, STOCK NO. 4720-916-1883, EXCEPT WHERE INDIVIDUAL COMPONENTS ARE ANNOTATED)	HOSE ASSEMBLY, DISCHARGE: RUBBER W/COUPLING SX937 (88795)	HOSE, DISCHARGE: 50 FT 546-622-048 (25500) (USED WITH HOSE ASSEMBLY, STOCK NO. 4720-916-1883, ONLY)	HOSE, SUCTION, FUEL: 10 FT 541-621-048 (25500) (USED WITH HOSE ASSEMBLY, STOCK NO. 4720-946-9960 ONLY)	стамр, ноse аroo5at (овчв)
(2) FEDERAL	STOCK										1720 <del>-</del> 946-9960	1720-916-1883	Andrew Control		
E SKR	NO.		χ20 20174	x20 00175	x20 00176	x20 00177	x20 00178	62100	00179A	x20 00180	00181	9 0 00182	х1 ∞183	×1 0018	x1 ∞185

		2		 <u> </u>					· m	6			2		9	<i>*</i>	
(11)	TRATION	(b)	9	 				<del></del>				-					
=	TRA	© G	Š.	=					=	=	Ξ		Ξ		=	=	
(10)	MAINT	ALW- PER	EQUIP				57										
(6)	ALW ALW	FOUR FOUR					δ.										
	GE	(c)	51-100				#										
30-DA)	GS MAIN! ALLOWANCE	3	21 50				2										
(8)	⊃ <b>₹</b>	(3)	1–20				.01										
> 5	ANCE	(c)	51-100	 			#							<del></del>			
30 DA	DS MAIN I	3	21-50				α										
12	_ <	<u>-</u> 3	1-20				~										
اق	710	Z Z E		ო	м	9	ω	m	9	· m	ო	m	m	m	9	12	
151	Ž Ž Ž Ž	UNIT PACK															
9 3	ınssı	. OE	רואט	EA	E.	EA	EA	£	ĘĄ	EA	EA	EA	ΕA	ξ	Ε¥	EA	
(3)	DESCRIPTION	NOT TRANSPORT	REFERENCE NO. & MFR. CODE	COUPLING, HALF QUICK 633C (81718)	COUPLER, HOSE, SHANK SX1616 (81718)	FINGER RING SX1605 (88795)	GASKET HG¥30M (81718)	PLUG ASSEMBLY, DUST SX1617 (88795)	CHAIN ASSEMBLY, SINGLE H6682M (81718)	PLUG, HOSE 634A (81718)	COUPLING HALF, QUICK 633E (81718)	CAP ASSEMBLY, DUST SX1604 (88795)	САР, HOSE 634В (81718)	CHAIN ASSEMBLY, SINGLE H6682M (81718)	GASKET H6430M (81718) (INITIALLY LISTED AS INDEX NO. 00189)	RING, FINGER SX1605 (88795)	
(2)	FEDERAL	STOCK		1,730-542-4031			1730-360-0595	-	4010-628-5276	1,130-595-3846	4730-542-4030		4730-555-1562	4010-628-5276	4730-360-0595		
ε	38	NOEX   SO	į	x1 00186	x1 00187	x1 00188	P 0 00189	x1 00190	x1 00191	x1 00192	х1 ∞193	х1 00194	x1 00195	x1 00196	P 0 7	x1 00198	

_		· ·	<del></del>										92					23
Ē	ILLUS- TRATION		ž S S										12 2	2 2				.2.
	_		5 Š															<u></u>
ê,	DEPOT	ALW PER	EQUIP													tion they're reading		
6	1-YR ALW	EQUIP NTGC			•											•		
		3	51-100															
-DAY	GS MAINT ALLOWANCE	<u>(a)</u>	8								······································							
	ALL	(0)	-20 21													,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		· · · · · · · · · · · · · · · · · · ·
(8)	μı	(5)	-100		1													
ρΑΥ	DS MAINT ALLOWANCE	(a)	21-50 51-100 1-20 21															
	DS A	·(0)	1-20 21			,												
(2)	ΥLC	N E	_			<b></b>	_				-	-	-				~	-
-		UNIT										<del></del>						
-		-5à				EA	EA.	E			EA	EA	EA	EA	ΕA	EA	EA	EA
-	31133:						<u> </u>					ω	ш	———	₩ ————	ш	LÚ	ш
(3)	DESCRIPTION		REFERENCE NO. & MFR. CODE USABLE ON CODE		2210 - DATA PLATES AND INSTRUCTION HOLDERS	DRIVE SCREW BHOOZA (88795)	IDENTIFICATION, PLATE G3020A2 (88795)	PLATE IDENTIFICATION: CYLINDER SHIELD 220478 (08645)	GROUP 72 - DISPENSING AND SERVICING EQUIPMENT COMPONENTS	7202 - PUMPS AND METERS	PUMP ASSEMBLY SX1603 (88795) (INCLUDES COMPONENTS OF KIT, STOCK NO. 4320-989-3259)	CASING ASSEMBLY SX1608 (88795)	CASING, PUMP E9001A1 (88795)	CAP ASSEMBLY, DUST SX1604 (88795)	CAP 6348 (81718)	CHAIN ASSEMBLY, SINGLE H6682M (81718)	FINGER, RING SX1605 (88795)	GADALI: UUST CAP H643CM (81718) (Initially Listed as Index No. 00189)
(2)		STOCK			-			2930-537-1364							4730-555-1562	4010-628-5276		4730-360-0595
ε	CODE	NOEX SEX	į	·	00199	X20 00200	X20 00201	x20 00202	00203	00203A	X20 00204	x1 00205	X2F 00206	x1 00207	x1 00208	X1 00209	X1 00210	P 0 00211

_		~ ×		#	22		7	27	₹2	12	m	91		=	80	8	12	
£	ILLUS- TRATION		ON O	 72	72	12	72	2	72	72	12	2	12	12	12	72	12	
			NO.				· 		·	·								
(01)	DEPOT	PER -	EQUIP								2			<del></del>	8			
6)	1-YR ALW	EQUIP CNTGCY									9				8			
		<u> </u>	51-100								8				-∞			
DAY	VANCE	<u> </u>	50 51.								*			,	#			<del>,</del>
30-	GS MAINT ALLOWANCE	<u>ə</u>	0 21												2		·	
(8)		(E)	1- 20								*							
  -	DS MAINT ALLOWANCE	ري	51–100	 							~				∞			
30 · D/	S MAI	<u> </u>	2150								*				#			
(7)	- V	(0)	1-20								*				N			
(9)	VTV CN	NIT		2	9	-	_	-	2	-	-	Æ	-	-	-	-	<i>#</i>	
(5)	ŽU NC ⊃	PACK													•			
Ę.:	enssi	10 T	ЛИП	EA	Z Z	EA	EA	<b>4</b>	EA	EA	EA	EA	E.	E	£.	EA	Z .	
(3)	DESCRIPTION		REFERENCE NO. & MFR. CODE USABLE ON CODE	BOLT, CARRIAGE: WEAR PLATE MTG BF001A1 (88795)	COUPLING, HALF QUICK: PUMP CASING 633F (81718)	ELBOW, SIDE OUTLET, PUMP: ALL ENDS FEMALE, 1 1/2-11 1/2 тно SIZE SX990 (88795)	HANDLE, PUMP C2002A1 (88795)	NIPPLE: 11/2 IN, ALUM, 2 IN LG PUMP CASING SX715 (88795)	NUT, CAP; PUMP CASING, 3/8-16 THD SIZE BG001A2 (88795)	PLUG, PIPE: 1/2 IN NPT PUMP CASING AJOO2A4 (88795)	PLATE, WEAR: PUMP C3012A1 (88795)	STUD, PUMP CASING: 3/8-16 NC, 1 1/4 IN LG BD001A1 (88795)	ADAPTER ASSEMBLY SX1609 (88795)	ADAPTER, PUMP 07002A1 (88795)	0 RING, SHAFT SEAT MS29513-216 (96906)	BOLT: PUMP MTG, 5/16-18 THD SIZE, 5/8 IN LG BEOCZAZ (88795)	ВО.Т.: РИНР ТО ENGINE MTG5/16-24 ТНО SIZE, 3/4 IN LG BEOO1A3 (88795)	
(2)	FEDERAL	STOCK			4730-805-6726				tal Tarabana		4350-946-9949	7Th 17 11 11 11 11 11 11 11 11 11 11 11 11			5330-250-0238	· manorination (Patrice)	**************************************	
ε	CODE	NDEX		X2F 00212	X20 00213	X20 00214	X20 00215	X20 00216	x20 00217	x20 00218	P F 1	X2F 00220	x20 00221	X2F 00222	P F 500223	X20 00224	X20 00225	

UNIT INC (a) (b) (c) (b) (c) (d) (e) (d) (e) (d) (e) (e) (e) (e) (e) (e) (e) (e) (e) (e	1 - 20 21 - 50 51 - 100 1 - 20 21 50 51 - 100  1 - 20 21 - 50 51 - 100 1 - 20 21 50 51 - 100  1	1	1	1	1	1	1	1	1
1 (a) (b) (c) (a) (b) 1-20 21-50 51-100 1-20 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1	1	1	1	1	1	1	1	1
1 * *	1 * * * * 5	1 * * 1	1 * * * * * * * * * * * * * * * * * * *	1 * * * * * * * * * * * * * * * * * * *	1 * * * 1	1 * * * * * * * * * * * * * * * * * * *	1	1	1
			7 7 7 7 7	1 7 2 1	7 7 7 7 1				
EA EA	E E E E A	E E E E E	E E A E E A E E A E A E A E A E A E A E	E E E E E E E E E E E E E E E E E E E	E E E E E E E E	E E E E E E E E E E E E E E E E E E E	E E E E E E E E E	E E E E E E E E E E E E E E E E E E E	E E E E E E E E E E
BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZA5 (88795) IMPELLER, PUMP A7004A1 (88795) NUT, HEXAGON; PUMP ADAPTER MTG, 3/8-16 THD SIZE BGOOZB3 (88795) NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZA5 (88795) IMPELLER, PUMP A700441 (88795) NUT, HEXAGON: PUMP ADAPTER MTG, 3/8-16 THD SIZE BGOOZB3 (88795) NUT, HEXAGON: PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOOIA1 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZA5 (88795) IMPELLER, PUMP A7004a1 (88795) NUT, HEXAGON: PUMP ADAPTER MTG, 3/8-16 THD SIZE BGOOZB3 (88795) NUT, HEXAGON: PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOOIA1 (88795) WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZA5 (88795) IMPELLER, PUMP A7004A1 (88795) NUT, HEXAGON: PUMP ADAPTER MTG, 3/8-16 THD SIZE BGOOZB3 (88795) NUT, HEXAGON: PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795) WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) WASHER, LOCK: PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZB2 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZAS (88795)  IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON; PUMP ADAPTER MTG, 3/8-16 THD SIZE BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB2 (88795)  KIT, PUMP SEAL AND GASKET KZ14:5 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZAS (88795)  IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZBS (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZBZ (88795)  WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AD001A1 (88795)  WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZBI (88795)  KIT, PUMP SEAL AND GASKET K, CASING GASKET, CASING B1004A1 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZA5 (88795)  IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, LCK; PUMP MTG, 5/16 IN SCREW SIZE AD001A1 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET K214:5 (88795)  GASKET, CASING B1004A1 (88795)  SEAL, SHAFT; 3/4 IN AEOOZA1 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THD SIZE, 1 IN LG BEOOZA5 (88795)  IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON: PUMP ADAPTER MTG, 3/8-16 THD SIZE BGOOZB3 (88795)  NUT, HEXAGON: PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB2 (88795)  KIT, PUMP SEAL AND GASKET KZ14-5 (88795)  KIT, PUMP SEAL AND GASKET KZ14-5 (88795)  SEAL, SHAFT: 3/4 IN AEOOZA1 (88795)  SEAL, SHAFT SEAL AGOOTA1 (88795)	BOLT, MACHINE: PUMP MTG, 5/16–18 THO SIZE, 1 IN LG BECOZZAŚ (88795)  IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON; PUMP ADAPTER MTG, 3/8–16 THO SIZE BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16–18 THO SIZE BGOOZB2 (88795)  WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK: PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZB2 (88795)  KIT, PUMP SEAL AND GASKET KZ14:5 (88795)  SEAL, SHAFT: 3/4 IN AEOOZA1 (88795)  SEAL, SHAFT SEAL AGOOTA1 (88795)  SEAL, SHAFT SEAL AGOOTA1 (88795)	BOLT, MACHINE: PUMP MTG, 5/16-18 THO SIZE, 1 IN LG BEOOZAS (88795)  IMPELLER, PUMP APOOAA1 (88795)  NUT, HEXAGON: PUMP MTG, 5/16-18 THD SIZE BGOOZB3 (88795)  WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB2 (88795)  WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB2 (88795)  KIT, PUMP SEAL AND GASKET K214:5 (88795)  SEAL, SHAFT: 3/4 IN AEGOZA1 (88795)  SEAL, SHAFT SEAL AEGOZA1 (88795)  SEAL, SHAFT SEAL AEGOZA1 (88795)  SLEEVE, SHAFT E400ZA1 (88795)
FER MTG, 3/8-16 THD 5/16-18 THD SIZE	IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON: PUMP ADAPTER HTG, 3/8-16 THD BGOOZB3 (88795)  NUT, HEXAGON: PUMP HTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, FLAT: PUMP HTG, 5/16 IN SCREW SIZE ADOOIA1 (88795)	IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON; PUMP ADAPTER HTG, 3/8-16 THD BG002B3 (88795)  NUT, HEXAGON; PUMP HTG, 5/16-18 THD SIZE BG002B2 (88795)  WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOOIA1 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHO02B1 (88795)	IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON: PUMP ADAPTER HTG, 3/8-16 THD BGOOZB3 (88795)  NUT, HEXAGON: PUMP HTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, FLAT: PUMP HTG, 5/16 IN SCREW SIZE ADOOIA1 (88795)  WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  WASHER, LOCK: PUMP ADAPTER, 3/8 IN SCREW SI	IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON; PUMP ADAPTER HTG, 3/8-16 THD BGOOZB2 (88795)  NASHER, FLAT; PUMP HTG, 5/16-18 THD SIZE ADOO1A1 (88795)  WASHER, LOCK; PUMP HTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  WASHER, LOCK; PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZB2 (88795)  KIT, PUMP SEAL AND GASKET K214-5 (88795)	IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON; PUMP ADAPTER HTG, 3/8-16 THD BG002B3 (88795)  NUT, HEXAGON; PUMP HTG, 5/16-18 THD SIZE BG002B2 (88795)  WASHER, FLAT: PUMP HTG, 5/16 IN SCREW SIZE AD001A1 (88795)  WASHER, LOCK; PUMP HTG, 5/16 IN SCREW SIZE AH002B1 (88795)  K1T, PUMP SEAL AND GASKET K214-5 (88795)  GASKET, CASING B1004A1 (88795)	IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON; PUMP ADAPTER HTG, 3/8-16 THD BG002B3 (88795)  NUT, HEXAGON; PUMP HTG, 5/16-18 THD SIZE BG002B2 (88795)  WASHER, ELAT: PUMP HTG, 5/16 IN SCREW SIZE AD001A1 (88795)  WASHER, LOCK: PUMP ADAPTER, 3/8 IN SCREW SIZE AH002B1 (88795)  KIT, PUMP SEAL AND GASKET K214-5 (88795)  GASKET, CASING B1004A1 (88795)  SEAL, SHAFT; 3/4 IN AE002A1 (88795)	IMPELLER, PUMP A7004a1 (88795)  NUT, HEXAGON; PUMP ADAPTER HTG, 3/8-16 THD BGOOZB2 (88795)  NUT, HEXAGON; PUMP HTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, FLAT; PUMP HTG, 5/16 IN SCREW SIZE ADOOIAI (88795)  WASHER, LOCK; PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET K214:5 (88795)  GASKET, CASING B1004A1 (88795)  SEAL, SHAFT; 3/4 IN AEOCZA1 (88795)  SEAL, SHAFT; 3/4 IN AEOCZA1 (88795)	IMPELLER, PUMP A7004A1 (88795)  NUT, HEXAGON: PUMP ADAPTER HTG, 3/8-16 THD BGOOZB2 (88795)  NUT, HEXAGON: PUMP HTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, ELAT: PUMP HTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK: PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET K214-5 (88795)  KIT, PUMP SEAL AND GASKET AHOOZB2 (88795)  SEAL, SHAFT: 3/4 IN AEOOZA1 (88795)  SEAL, SHAFT SEAL AGOO1A1 (88795)  SLEEVE, SHAFT SEAL AGOO1A1 (88795)  SLEEVE, SHAFT SEAL	IMPELLER, PUMP A7004a1 (88795)  NUT, HEXAGON; PUMP ADAPTER HTG, 3/8-16 THD BGOOZB2 (88795)  NUT, HEXAGON; PUMP HTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, ELAT; PUMP HTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  WASHER, LOCK; PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET K214:5 (88795)  GASKET, CASING B1004a1 (88795)  SEAL, SHAFT; 3/4 IN AECOZA1 (88795)  SLEEVE, SHAFT E400ZA1 (88795)  SLEEVE, SHAFT E400ZA1 (88795)
тек мтс, 3/8-16 тно 5/16-18 тно size	тек мта, 3/8-16 тно 5/16-18 тно size 5/16 in screw size	MTG, 3/8-16 THD 16-18 THD SIZE 16 IN SCREW SIZE 16 IN SCREW SIZE	4TG, 3/8-16 THD 5-18 THD SIZE 5 IN SCREW SIZE 5 IN SCREW SIZE 5 IN SCREW SIZE 3/8 IN SCREW SI	NUT, HEXAGON; PUMP ADAPTER MTG, 3/8-16 THD BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, LAT; PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET K214-5 (88795)	NUT, HEXAGON; PUMP ADAPTER MTG, 3/8-16 THD BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, EAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  WASHER, LOCK; PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZB2 (88795)  KIT, PUMP SEAL AND GASKET  KZ14-5 (88795)  GASKET, CASING  B1004A1 (88795)	NUT, HEXAGON; PUMP ADAPTER MTG, 3/8-16 THD BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET K214-5 (88795)  GASKET, CASING B1004A1 (88795)  SEAL, SHAFT; 3/4 IN AEOOZA1 (88795)	NUT, HEXAGON; PUMP ADAPTER MTG, 3/8-16 THD BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET  KZ14-5 (88795)  KIT, PUMP SEAL AND GASKET  KZ14-5 (88795)  SEAL, SHAFT; 3/4 IN  AEOOZA1 (88795)  SEAL, SHAFT; SEAL  AGOO1A1 (88795)	NUT, HEXAGON; PUMP ADAPTER MTG, 3/8-16 THD BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, FLAT; PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET K214-5 (88795)  GASKET, CASING B1004A1 (88795)  SEAL, SHAFT; 3/4 IN AEOCZA1 (88795)  SEAL, SHAFT SEAL AGOOZA1 (88795)  SEAT, SHAFT SEAL AGOOZA1 (88795)  SLEEVE, SHAFT SEAL AGOOZA1 (88795)  SLEEVE, SHAFT SEAL AGOOZA1 (88795)	NUT, HEXAGON; PUMP ADAPTER MTG, 3/8-16 THD BGOOZB3 (88795)  NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795)  WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795)  KIT, PUMP SEAL AND GASKET  KZ14-5 (88795)  SEAL, SHAFT; 3/4 IN  AECOZA1 (88795)  SEAT, SHAFT SEAL  AGOO1A1 (88795)  SLEEVE, SHAFT  E400ZA1 (88795)
5/16-18 THD SIZE	5/16-18 THD SIZE 5/16 IN SCREW SIZE	16-18 THD SIZE 16 IN SCREW SIZE 16 IN SCREW SIZE	5-18 THD SIZE IN SCREW SIZE IN SCREW SIZE 3/8 IN SCREW SIZE	NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT; PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795) WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOC2B1 (88795) KIT, PUMP SEAL AND GASKET KZ14:5 (88795)	NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADDOIL1 (88795) WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) KIT, PUMP SEAL AND GASKET K214-5 (88795) GASKET, CASING B1004A1 (88795)	NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT; PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795) WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) KIT, PUMP SEAL AND GASKET K214-5 (88795) GASKET, CASING B1004A1 (88795) SEAL, SHAFT; 3/4 IN AEOOZA1 (88795)	NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOOIA1 (88795) WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) KIT, PUMP SEAL AND GASKET K214:5 (88795) GASKET, CASING B1004A1 (88795) SEAL, SHAFT: 3/4 IN AEGOZA1 (88795) SEAL, SHAFT: 3/4 IN AEGOZA1 (88795)	NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT; PUMP MTG, 5/16 IN SCREW SIZE ADOOIA1 (88795) WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB2 (88795) KIT, PUMP SEAL AND GASKET K214:5 (88795) SEAL, SHAFT; 3/4 IN AEOOZA1 (88795) SEAT, SHAFT; SAL AGOOIA1 (88795) SEAT, SHAFT SEAL AGOOIA1 (88795) SLEEVE, SHAFT SLEEVE, SHAFT SLEEVE, SHAFT	NUT, HEXAGON; PUMP MTG, 5/16-18 THD SIZE BGOOZB2 (88795) WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOOIA1 (88795) WASHER, LOCK; PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) KIT, PUMP SEAL AND GASKET K214:5 (88795) SEAL, SHAFT; 3/4 IN SEAL, SHAFT; 3/4 IN AECOZA1 (88795) SLEVE, SHAFT E400ZA1 (88795) SLEEVE, SHAFT E400ZA1 (88795)
	5/16 IN SCREW SIZE	16 IN SCREW SIZE	S IN SCREW SIZE IN SCREW SIZE 3/8 IN SCREW SIZE	5/16 IN SCREW SIZE 5/16 IN SCREW SIZE TER, 3/8 IN SCREW SIZE	WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795) WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) WASHER, LOCK: PUMP ADAPTER, 3/8 IN SCREW SIZE AHOOZB2 (88795) KIT, PUMP SEAL AND GASKET KZ14:5 (88795) GASKET, CASING B1004A1 (88795)	WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795) WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) KIT, PUMP SEAL AND GASKET K214:5 (88795) GASKET, CASING B1004A1 (88795) SEAL, SHAFT: 3/4 IN AEOOZA1 (88795)	WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795) WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) KIT, PUMP SEAL AND GASKET K214:5 (88795) GASKET, CASING B1004A1 (88795) SEAL, SHAFT: 3/4 IN AEOOZA1 (88795) SEAT, SHAFT SEAL A6601A1 (88795)	WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795) WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) KIT, PUMP SEAL AND GASKET K214:5 (88795) GASKET, CASING B1004A1 (88795) SEAL, SHAFT: 3/4 IN AEOOZA1 (88795) SEAT, SHAFT SEAL AGOO1A1 (88795) SLEEVE, SHAFT SLEEVE, SHAFT SLEEVE, SHAFT SLEEVE, SHAFT SLEEVE, SHAFT SLEEVE, SHAFT	WASHER, FLAT: PUMP MTG, 5/16 IN SCREW SIZE ADOO1A1 (88795) WASHER, LOCK: PUMP MTG, 5/16 IN SCREW SIZE AHOOZB1 (88795) KIT, PUMP SEAL AND GASKET K214-5 (88795) GASKET, CASING B1004A1 (88795) SEAL, SHAFT: 3/4 IN AECOZA1 (88795) SEAL, SHAFT: SEAL A6001A1 (88795) SLEEVE, SHAFT E400ZA1 (88795)

-S	N (a)	NO N		_		#		Ξ	ω.	N	_	10	5	6	9	8	
(11) ILLUS-	7	NO.		<u>E</u>		5		5		13	13	13	13	13	13	13	
(10) DEPOT	MAINT ALW- PER	EQUIP		5													
(9) 1-YR	ALW PER 100 EQUIP	מו פר	7	2													
	- T	51-100		*													
30-DAY GS MAINT	OWANC (b)	21. 50 5		*													
(8) GS	(a)	1-20 2		*													
	E E	51-100		*	X.	<del>~</del>				***************************************							
30. DAY DS MAINT	(b)	21-50		*													
(2)	(o)	1–20		*													
(9)	ÇN N L			_	-		-	-		<del>-</del>	-	8	-	-	-	-	
(S)	NEN	FACA						1									
5 ∃೧	OE :22	TINU		EA	ΕΛ	Ε¥	EA	EA	EA	E.	EA	EA	EA	Ε¥	EA	Ε¥	
(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE USABLE ON CODE		CAP ASSEMBLY, SPOUT 296C (81718)	COUPLING, HALF, QUICK 633B (81718)	NOZZLE 210 (81718)	PLUG ASSEMBLY, DUST SX1617 (88795)	СНАIN, BRASS; 6 ім Н6682M (81718)	COUPLER SX888 (81718)	GASKET HG430M (81718) (İMITIALLY LISTED AS İNDEX NO. 00189)	PLUG, DUST 63¼A (81718)	ring, finger sx1605 (88795)	SCREEN, FILTER: 100 MESH 153 (81718)	SCREW, GROUNDING WIRE SX1048 (88795)	SPOUT, RIGID: NOZZLE ASSEMBLY CC2961 1-2X1 5-8 (81718)	WIRE ASSEMBLY, GROUNDING 1904 (81718)	
(2)	FEDERAL STOCK NUMBER	REFERE		5340-531-7989 CAP AS	4730-715-1558 coupt.1	NOZZLE 210	PLUG A SX16	CHA1 H668	COUP SX88	4730-360-0595 GASK H643 (1,	4730-595-3846 PLUG	RING SX16	SCREEN 153	SCREW, G	SPOUT, R	WIRE A	
€ 8	CODE NDEX	NO.		P F 55	x20 4- 00241	х <b>1</b> 00242	x20 00243	х20 00244	x20 00245	P 0 47	x20 00247	x20 00248 <sup>7</sup>	<b>х1</b> 00249	x20 00250	x20 00251	x20 00252	

.

FEDERAL	10 Haid 23 BC	nss				DS MAJNT ALLOWANCE	NCE	AL	GS MAINT ALLOWANCE	 . U	1-YR	MAINT		ILLUS- TRATION
STOCK	DESCRIPTION	gi aò Til	PACK	N N N	3	[9]	ادر	(0)	(9)	<u> </u>	PER. 100 EQUIP CNTGCY	ALW- PER 100	_	(b)
	REFERENCE NO. & MFR. CODE USABLE ON CODE		NO.	_	1–20	21-50	51-100	1-20	21. 50	51-100				<u>S</u>
	7204 - MISCELLANEOUS PARTS AND ACCESSORIES													
	GAGE ASSEMBLY, GO-NO-GO: 100 GPM SX1611 (88795)	<u></u>	EA	_										
	GAGE, GO-NO-GO: 100 GPM O <sup>44</sup> 107S (9000 <del>5</del> )	ш	E A	-									7	9
	CLAMP, GAGE GO-NO-GO AR010A1 (08484)	EA		۷	1								Ē	- 70
	COVER, END 100 GPM SX1613 (88795)	EA	<b>—</b>										Ť.	ī.
4930-872-1779	ELEMENT, FILTER O41420S (90005)	EA		7	#	∞	11	<b>A</b>	ω	17	8	8 	15	
	HOUSING, GAGE GO-NO-GO SX1660 (90005)	EA	<b>4</b>	-									15	m
5330-526-7517	0 RING, 100 GPM GAGE MS29513-2 <sup>1</sup> 9 (96906)	EA	⋖	_	2	#	∞	N	≉	∞	.8	<u>§</u>	15	
	ADAPTER, HOSE MAB6 (88795)	EA	<b>4</b>	~			·		)				17	∞
4730-805-6726	ADAPTER, HOSE: 1 1/2 IN 633F (81718)	EA		~									14	~
	CAP ASSEMBLY, DUST SX1604 (88795)	EA		2									<b>2</b>	<i>≯</i>
Westernessel	DUST САР 634в (88795)	EA		~		***************************************								
	FINGER RING SX1605 (88795)	EA		#										•
4730-360-0595	GASKET HG430M (81718) (Initially listed as Index No. 00189)	E P		N									<u>*</u>	m 

	18 3 3	NO NO		0	12	9	7	~	=		ന			_		
E =	15 <b></b>	F1G NO.		4	<u> 7</u>	₫	₹ <u></u>	<u>₹</u>	<u>†</u>		<u></u>		·	7		
(10)				80				7								
(6)	ALW ALW PER 100 EQUIP	NTGCY		8				2	·							
	_	51-100		N				*							-	
0-DAY	ALLOWANCE (c	2) 50 5	 	7				*								
(8)	2   VE	1.20		*	10			*								
	NCF (S)	51 - 100		2				*								
YAY OF.	CI.OWA	21 50		2				*								
5	3	1 20		*				*								
9	ZN ZN Z		2	#	<del>-</del>	_	-	. ~	-	N.	-	-	-	-		
15,	PAN E	יארא														
5 31	סב יצצח	T:MU	ΕA	EA	ξA	ΕA	EA	ε¥	EA	EA	Ę	Ε¥	Ε¥	E		
(3)	DESCRIPTION	REFERENCE NO. & MFR. CODE	CHAIN, ASSEMBLY, SINGLE H6682M (81718)	clamp, hose qszoomz8a (88795)	COUPLER: 1 1/2 IN 633H (81718)	HOSE, GAGE CONNECTING SX1619 (88795)	NIPPLE: 11/2, ALUM, 2 IN LG SX715 (88795)	GAGE, PRESSURE, DIAL 022-171 (38508)	PLUG ASSEMBLY, DUST SX1617 (88795)	FINGER RING SX1605 (88795)	GASKET H6430M (81718) (Initially Listed as Index No. 00189)	PLUG, HOSE 634A (81718)	CHAIN ASSEMBLY, SINGLE H6682M (81718)	TEE, ALUM: 1 1/2, 1/2 × 1/2 SX733 (88795)		
(2)	FEDERAL STOCK NUMBER		4010-628-5276	1320-920-5342	1730-02 <b>0-</b> 9293			6685-923-7077			4730-360-0595	4730-595-3846	4010-628-5276			
ε	CODE	o N	x1 00266	P 0 00267	x20 00268	x20 00269	x20 00270	P 0 00271	x20 00272	x1 00273	P 0 ,	x1 00275	x1 00276	x20 00277		




FIGURE No. 1 CYLINDER, VALVES AND CAMSHAFT

	ITEM NAME	ITEM NO.	FUNCT GROUP	ITEM NAME	ITEM NO.	FUNCT GROU <b>P</b>	ITEM NAME
0105	TADDET	7	0100	SACUED	4.0		•
		1	0100	NASHEK	13	0105	PIN
0105	VALVE	8	0100	BOLT	1 L	0105	RETAINER
0105	VALVE	•					
-		9	וטוט	PLUG	15	0105	ROTATOR CAP
0101	CYLINDER AY	10	0105	SPRING	16	0105	SPRING
0101		-					
		11	0105	SEAT	17	0105	CAMSHAFT
0100	NUT	12	0105	DIN	• •	,	
		OTOS TAPPET OTOS VALVE OTOS VALVE OTOS VALVE OTOT CYLINDER AY OTOT SEAL	O105 TAPPET 7 0105 VALVE 8 0105 VALVE 9 0101 CYLINDER AY 10 0101 SEAL 11	GROUP NAME NO. GROUP  0105 TAPPET 7 0100 0105 VALVE 8 0100 0105 VALVE 9 0101 0101 CYLINDER AY 10 0105 0101 SEAL 11 0105	GROUP NAME  0105 TAPPET 7 0100 WASHER 0105 VALVE 8 0100 BOLT 0105 VALVE 9 0101 PLUG 0101 CYLINDER AY 10 0105 SPRING 0101 SEAL 11 0105 SEAT	GROUP NAME NO. GROUP NAME NO.  1005 TAPPET 7 0100 WASHER 13 0105 VALVE 8 0100 BOLT 14 0105 VALVE 9 0101 PLUG 15 0101 CYLINDER AY 10 0105 SPRING 16 0101 SEAL 11 0105 SEAT 17	GROUP NAME NO. GROUP NAME NO. GROUP  0105 TAPPET 7 0100 WASHER 13 0105 0105 VALVE 8 0100 BOLT 14 0105 0105 VALVE 9 0101 PLUG 15 0105 0101 CYLINDER AY 10 0105 SPRING 16 0105 0101 SEAL 11 0105 SEAT 17 0105




FIGURE NO. 2 CYLINDER COVER AND GOVERNOR

FUNCT GROUP	I TEM NAME
0101	BOLT
0101	COVER
0101	GASKET
0308	WASHER
0308	FOLLOWER
0308	RETAINER
0308	GEAR
0308	BODY
0308	SCREW
0308	SHAFT
0106	CAP
0106	NIPPLE
0308	SHAFT
0308	WASHER
0308	PIN
0101	SEAL
	GROUP  0101 0101 0101 0308 0308 0308 0308 030




FIGURE No. 3 PISTON, CONNECTING ROD AND CRANKSHAFT

NO.	FUNCT Group	ITEM NAME	ITEM	FUNCT GROUP	ITEM NAME
1	0104	RING	6	0104	LOCK
2	0104	PIN	7	0104	BOLT
3	0104	PISTON AY	8	0104	DIPPER
4	0104	RING SET	9	0102	CRANSHAFT
5	0104	ROD AY	10	0102	BEARING




FIGURE No. 4 REWINDSTARTER, FLYWHEEL AND SHROUD

ITEM NO.	FUNCT GROUP	I TEM NAME	NO.	FUNCT Group	ITEM NAME	NO.	FUNCT GROUP	ITEM Name
1	0502	COVER	8	0502	WASHER	15	0107	RATCHET
2	0107	ROPE	9	0107	PULLEY	16	0107	BEARING
3	0107	SPRING	10	0107	BUMPER	17	0107	HOUS ING
ų	0502	HOUSING	11	0107	SCREW	18	0605	WASHER
5	0107	GRIP	12	0107	SCREEN	19	0605	WASHER
6	0107	PIN	13	0107	WASHER	20	0605	FLYWHEEL AY
7	0502	SCREW	14	0107	WASHER			




FIGURE No. 5 CRANKCASE BREATHER

•	NO.	FUNCT GROUP	I TEM NAME	ITEM NO.	FUNCT GROUP	ITEM NAME
	1	0502	SCREW	5	0106	GROMMET
	2	0502	SHIELD	6	0106	TUBE
	3	0106	GASKET	7	0106	GROMMET
	4	0106	BREATHER	8	0106	80LT

	FUNCT GROUP	ITEM NAME
1	0304	SCREW
2	0304	AIR CLEANER
3	0304	FILTER ELEMENT
4	0304	GASKET
5	0301	SCREW
6	0301	GAS KET
7	0301	CARBURETOR AY
8	0306	GASKET
9	0306	TANK
10	0306	SCREW
11	0306	CAP
12	0301	SCREW

4320-248-25P/6

10

FIGURE No. 6 FUEL TANK, CARBURETOR AND AIR CLEANER




FIGURE No. 7 CARBURETOR

NO.	FUNCT Group	ITEM NAME	ITEM NO.	FUNCT GROUP	ITEM NAME
1	0301	SCREW	11	0301	CRANK
2	0301	SPRING	12	0301	SCREW
3	0301	SPRING	13	0301	VALVE
ų	0301	CAP	14	0301	SPRING
5	0301	DIAPHRAGM	15	0301	WASHER
6	0301	PIN	16	0301	PACKING
7	0301	COVER	17	0301	NUT
8	0301	SCREW	18	0301	GASKET
9	0301	SPRING	19	0301	SEAT
10	0301	LIMC			




FIGURE No. 8 MUFFLER AND GOVERNOR CONTROLS

ITEM NO.	FUNCT Group	ITEM NAME	ITEM NO.	FUNCT GROUP	I TEM NAME
1	0401	LOCKNUT	10	0308	BUSHING
2	0401	MUFFLER	11	0308	SCREW
3	0308	NUT	12	0308	BRACKET
4	0308	SPRING	13	0308	SPRING
<u>.</u>	0308	BRACKET	14	0308	LINK
6	0308	ROD	15	0308	SPRING
7	0308	LEVER	16	0308	LEVER
8	0308	WASHER	17	0308	SCREW
9	0308	SCREW			_





FIGURE No. 9 CYLINDER HEAD AND IGNITION COMPONENTS.

ITEM NO.	FUNCT Group	ITEM Name	ITEM NO.	FUNCT GROUP	ITEM NAME	ITEM NO.	FUNCT GROUP	ITEM NAME
1	0101	BOLT	8	0605	SCREW	15	0605	CLAMP
2	0101	HEAD	9	0605	COVER	16	0605	WIRE
3	0605	PLUG	10	0605	· SCREW	17	0605	BOLT
4	0101	BOLT	11	0605	SPRING	18	0605	WASHER
5	0605	LEAD	12	0605	PARTS KIT	19	0605	INSULATOR
6	0605	ARMATURE	13	0605	PLUNGER	20	0605	NUT
7	0502	DEFLECTOR	14	0605	SCREW	21	0101	GASKET




4320-248-25P/10

FIGURE No. 10 BASKET AND FRAME

LEGEND	TO	PARIS,	FIGURE	10

ITEM NO.	FUNCT GROUP	I TEM NAME	ITEM No.	FUNCT Group	ITEM Name	ITEM NO.	FUNCT GROUP	I TEM NAME
1	1.501	NUT	4	1501	SUPPORT	7	1501	WASHER
2	1501	SPACER	5	1501	BOLT	8	1501	BASKET
_	1501	RASE	6	1501	NUT	9	1501	BOLT






FIGURE No. 11 Hose

ITEM NO.	FUNCT GROUP	ITEM- NAME
1	2202	HOSE
2	2202	HOSE
3	2202	CHAIN AY
4	2202	RING
.5	2202	CAP
6	2202	GASKET
7	2202	COUPLING
8	2,202	CLAMP
9	2202	PLUG
10	2202	COUPLING




FIGURE No. 12 PUMP

ITEM NO.	FUNCT GROUP	NAME	ITEM NO.	FUNCT GROUP	ITEM NAME	ITEM NO.	FUNCT GROUP	ITEM NAME
1	7202	ELBOW	10	7202	GASKET	19	7202	NU T
2	7202	HANDLE	11	7202	ADAPTER	20	7202	BOLT
3	7202	PLATE	12	7202	BOLT	21	7202	PLUG
4	7202	BOLT	13	7202	WASHER	22	7202	CAP AY
5	7202	IMPELLER	14	7202	NUT	23	7202	GASKET
6	7202	SEAL	15	7202	WASHER	24	7202	NUT
7	7202	SLEEVE	16	7202	STUD	25	7202	COUPLING
8	7202	O RING	17	7202	BOLT	26	7202	CASING
9	7202	SEAT	18	7202	WASHER	27	7202	NIPPLE




FIGURE No. 13 NOZZLE

ITEM NO.	FUNCT GROUP	TTEM NAME
ŧ	7203	PLUG
2	7203	GAS KET
3	7203	COUPLER
•	7203	NOZZLE
5	7203	SCREEN
6	7203	SPOUT
7	7203	CAP AY
8	7203	WIRE AY
9	7203	SCREW
10	7203	RING
11	7203	CHAIN





FIGURE No. 14 MONITOR

ITEM NO.	FUNCT GROUP	ITEM NAME	ITEM NO.	FUNCT Group	I TEM NAME
1	7204	TEE	7	7204	GAGE
2	7204	ADAPTER	8	7204	ADAPTER
3	7204	GASKET	9	7204	CLAMP
<b>l</b>	7204	CAP AY	10	7204	HOSE
5	7204	NIPPLE	11	7204	PLUG AY
6	7204	GAGE	12	7204	COUPLER



#### FIGURE No. 15 GAGE GO - NO - GO

ITEM NO.	FUNCT GROUP	NAME
1	7204	ELEMENT
2	7204	CLAMP
3	7204	HOUSING
4	7204	O RING
5	7204	COVER

# Section VII. INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO INDEX NUMBER

STOCK NUMBER	INDEX NUMBER	STOCK NUMBER	INDEX NUMBER
2805-018-5293	00048	4010-628-5276	00209
2805-254-1370	00044		00266
2805-342-7432	00042		00276
2805-351-6692	00020	4320-920-5342	00267
2805-353-7587	00041	4320-920-5343	00237
2805-353-7712	00030	4320-946-9947	00236
2805-356-1334	00043	4320-946-9948	00227
2805-422-5804	00052	4320-946-9949	00219
2805-594-1030	00023	4320-946-9961	00239
2805-608-8508	00035	4320-989-3259	00233
2805-608-8509	00032	4720-916-1883	00182
2805-624-0278	00021	4720-946-9960	00181
2805-624-0282	.00051	4730-020-9293	00268 00056
2805-624-0284	00158	4730-192-9481	00189
2805-658-3916	00017	4730-360-0595	00189
2805-678-4395	000 08		00211
	00022		.00246
2805-678-4421	00038		00274
2805-678-4423	00034 00046	4730-360-1595	00265
2805-678-4425	00046	4730-542-4030	00193
2805-678-4431	000 53	4730-542-4031	00186
2005 (70 (/22	00007	4730-555-1562	00195
2805-678-4432	00018	4130 333 1302	00208
2005-470-5770	00118	4730-595-3846	00192
2805-679-5779 2805-679-5784	00116	7,50 575 5040	00247
2805-776-2282	00054		00275
2805-828-0783	0 00 04	4730-715-1558	00241
2805-828-0765	00057	4730-805-6726	00213
2805-920-5383	0 00 19		00261
2805-920~5384	00027	4730-950-7613	00024
2805-920-5385	00153	4930-872-1779	00257
2805-920-5387	00036	5305-010-0752	00150
2805-920-5388	0 00 47	5305-543-5220	00164
2805-949-0543	00029	5305-719-4603	00144
2805-992-0403	0 00 45		00069
2805-999-5238	00003		00163
2910-707-7503	00107	5305-719-4783	00129
2910-711-5609	00130	5305-753 <i>-</i> 4269	00127
2910-893-5072	00082	5305-992-0440	00162
2910-893-5073	00088	5306-073-8255	00050
2910-898-2094	00108	5306-543-5219	00128
29 10 -8 9809 4	00009	5306-817-0730	00033
2910-920-5361	0 00 74	5310-011-5544	00166
2910-920-5363	00087	5310-353-7577	00135 00157
2910-920-5368	00078	5310-596-5224 5310-721-4667	00165
2910-920-5369	00075 00076	5315-248-0052	.00040
2910-920-5370 2910-920-5371	00080	5315-276-4081	00039
2910-920-3371	00080	5315-598-5970	00155
29 20 - 213 - 1147	00156	5315-626-1789	00123
2920-294-3747	00160	5315-855-4336	00064
2920-356-1333	00161	5315-924-0051	`00085
2920-537-1365	00152	5330-250-0238	00223
2920-920-5373	00149	5330-526-7517	00259
2930-537-1360	00142	5330-924-0049	00084
29 30 -5 37 -1 36 3	00141	5330-924-0050	00234
2930-537-1364	00202	5330-924-0090	00079
2940-171-7935	00006	5340-286-4566	00159
2110 212 1122	000 94	5340-356-1325	00031
2940-294-1599	00101	5340-531-7989	00240
2940-608-8514	000 05	5340-923-7050	00090
	00103	5340-923 <b>-</b> 9875	00089
2940-688-7912	00102	5340-945-0493	00132
2990-174-5255	00067	5840-787-6662	00061
2990 <b>-2</b> 69 <b>-71</b> 45	00139,	5970-789-1925	00154
2990-624-0260	00131	5975-152-1075	00138
2990-678-1220	00136	6150-624-0279	00167
2990-768-0723	00062	6685-923-7077	00271
2990-769-4104	00070		
2990-786-2030	00065		
2990-787-6665	00116		
2990-898-2097	00133		
2990-907-0644	00059		
2990-920-5347	00121		
2990-930-1737	00066		
2990-930-1738	00068		
2990-992-0405	00111 00060		
3110-100-6180 3110-144-9004	00026		
4010-628-5276	00191		
1010 050 3510	0010.		
	50.		

BECTION VII. INDEX-FEDERAL STOCK NUMBER AND REFERENCE NUMBER CROSS-REFERENCE TO INDEX NUMBER

FERENCE No.	MFG CODE	INDEX No.	REFERENCE No.	MFG CODE	INDEX No.
>001A1	88795	00230	SX888	81718	00245
:002A1	88795	00235	SX931A	88795	00239
1002B1	88795	00012	SX 9 3 7	88795	00182
		00178	5X988	88795	00176
		0231 -	SX 98 9	88795	00175
1002B2	88795	00232	SX990	88795	00214
1002A4	88795	00218	022-171	38508	00271
.005Al	08484	00185	0414205	90005	00257
:0 10 A1	08484	00255	0441075	90005	00255
-001A1	88795	00236	153	81718	00249
'004Al	88795	00227	190W	81718	00252
001A1	88795	00220	210	81718	00242
:002A7	88795	00172	210226	08645	00113
001A3	88795	00225	210227	08645	00112
:002A2	88795	00224	210453	08645	00038
00 2 A 5	88795	00226	210812	08645	00023
:002A7	88795	00002	210959	08645	00076
001A1	88795	00212	211383	08645	00063
-001A2	88795	00217	220366	08645	00152
002B2	88795	00011	220381	08645	00118
		00174	220478	08645	00146
		00229			00202
00283	88795	00228	220581	08645	00141
OU 2A	88795	00200	220670	08645	00034
.004A1	887 95	00234	220680	08645	00136
2961 1-2X1 5-8	81718	00251	220690	08645	00120
18	08645	00160	220691	08645	00116
002A1	88795	00215	220692	08645	00142
012A1	88795	00219	220756	08645	00035
00 2 A 1	88795	00222	220865	08645	00165
002A1	88795	00237	221377	08645	00075
001A1	88795	00206	221384	08645	00115
0 20 A 2	88795	00201	22165 3	08645	00071
430M	81718	00189			00068
430M	01/10	00197	22166 i 22235	08645 08645	00093
		00197	22826	08645	00135
			230126	08645	00039
		00246 00265	230127	08645	00039
		00274	230127	08645	00122
4034	91710	00191			00122
682M	81718	00191	230173 230177	08645 08645	00124
		00209	230181	08645	00124
		00244	230228	08645	00064
		00266	230445	08645	00114
		00276	230590	08645	00083
14-5	88795	00233	230591	08645	00087
.86	88795	00260	230634	08645	00057
29513-216	96906	00223	230671	08645	00096
29513-249	96906	00259	230680	08645	00125
200M28A	88795	00267	23184	08645	00043
1048	88795	00250	23187	08645	00040
1077	88795	00180	23433	08645	00082
1091	88795	00177	23688	08645	00117
1094	88795	00173	26018	08645	00159
1603	88795	00204	260182	08645	00027
1604	88795	00194	26026	08645	00027
1804	00193				
		00207	26045 5	08645	00090
1406	00705	00262	260544	08645	00151 00121
1605	88795	00188 00198	260545	08645 08645	00121
				08645	00152
		00210	260552		00043
		00248 00264	260563 260564	08645 08645	00091
		00273	260575	08645	00091
1608	88795	00215	260515	08645	00133
1609	88795	00221	26336	08645	00089
		00169	26478	08645	00044
1610 1611	88795 88795	00254	26855	08645	00131
1613	88795	00256	270026	08645	00078
1616	81718	00187	27402	08645	00076
1617	88795	00190	27549	08645	00010
1011	30175	00243	-1277	000+3	00053
		00272	27586	08645	00007
1410	99705	00272	21300	00047	00018
1619	88795	00269	27660	08645	00018
1644A	88795		21000	V0043	
1644B	88795	0170A	27470	00//5	00103
1660	90005	00258	27670	08645	00008
700	88795	00171	27011	00//5	00022
7 15	88795	00216	27911	08645	00009
7 2 2	00705	00270	27007	00115	00108
733	88795	00277	27987	08645	00102
848	. 88795	00181	291925	08645	0 <b>0</b> 0 <b>30</b>

REFERENCE No.	MFG CODE	INDEX No.	REFERENCE No.	Mra Code
202250	08645	00042	93113	08645
292259 293141	08645	00156	93141	08645
293270	08645	00107	93265	08645 08645
29 3740	08645	00021 00167	93322 93341	08645
293999	08645 08645	00119	93343	08645
294077 294088	08645	00065	93357	08645
294178	08645	00051	93381	08645
294 260	08645	00143	93392	08645 08645
294303	08645	00070	93394 99158	08645
294306	08645 08645	· 00017	77130	
294367 294584	08645	00067		
294628	08645	00158		,
294870	08645	00101		
294932	08645 08645	00111 00029		
295455	08645	00023		
295657 296C	81718	00240		
296178	08645	00080		
296591	08645	00106	•	
296610	08645 08645	00019 00047		
296676 296677	08645	00048		
. 296784	08645	00074		
296811	08645	00086		
296 884	08645	00153		
297069	08645	00077 00004		
297 275	08645 08645	00004	•	
297961 298310	08645	00059		
298436	08645	00066		
298502	08645	00149		
541-621-048	25500	0084 00183		
546-622-048	255 00 08645	00155		
61760 6338	81718	00241		
63 3C	81718	00186		
633E	81718	00193		
63 3F	81718	00213 00261		
63 3H	81718	00268		
634A	81718	00192		
0344		00247		
		00275		
634B	81718	00195 00208		
•	88795	00263		
63770	08645	0 0 0 6 0		
65704	08645	00161		
65978	08645	00084 00134		
66432	08645 08645	00061		
66528 66578	08645	00054		
66594	08645	00079		
66728	08645	00062	•	
66935	08645	00154		
67608	08645 08645	00055 00072		
68238 69345	08645	00052		
81232	08645	00003		
89660	08645	00020		
89966	08645	00139 00157		
90576	08645 08645	00024		
91249 91258	08645	00056		
9 18 11	08645	00138		
92296	08645 08645	00033 00145		
9 26 66	08645	00147		
92778 92786	08645	00150		
93014	08645	00164		
93032	08645	00014		
93042	08645	00144		
		00069 00163		
03043	08645	00103		
93043 93062	08645	00126		
93064	08645	00127		
93067	08645	00128		
93 100	08645 08645	'0012 <i>9</i> '00015		
93111	U0043	00017		



INDEX No.

By Order of the Secretary of the Army:

Official:

HAROLD K. JOHNSON, General, United States Army, Chief of Staff.

KENNETH G. WICKHAM, Major General, United States Army, The Adjutant General.

To be distributed in accordance with DA Form 12-25, Section I, requirements for Organizational Maintenance, Mobility Support Equipment for Pumps, Centrifugal, Petroleum.